



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1655	7333A27	GEAR HOUSING ASSEMBLY, CO	1	(SHORT SHAFT)	
-	1655	7333A25	GEAR HOUSING ASSEMBLY, CO	1	(LONG SHAFT)	
1	1655	7333A23	GEAR HOUSING ASSY	1		
51		76039	SHIFT CAM	1		
52		30625	CAM FOLLOWER	1		
53		30624	SLIDE, CROSS PIN	1		
54	24	30622	SPRING, COMPRESSION - CAM	1		
55	15	30923A 1	SHIM	AR	BEARING OUTER RACE TO GEAR 3	
56	31	30894A 1	TAPERED ROLLER BEARING A	1		
57	31	30895	ROLLER BEARING, FORWARD	1		
58	43	75314A 2	FORWARD GEAR	1		
59	52	34239	RATCHET, SLIDING CLUTCH	1		
60	17	30632	CROSS PIN, RATCHET TO PRO	1		
61	24	30893	SPRING, RETAINING - CROSS F	1		
62	44	93003	PROPELLER SHAFT	1		
63	43	77562	REVERSE GEAR	1		
65	12	76805	THRUST WASHER	1	BEARING CARRIER TO GEAR H	
67	25	29976	"O" RING, BEARING CARRIER	1		2
68		96074A 1	BEARING CARRIER ASSEMBLY	1	(W/O GREASE FITTING)	
68		41529A 1	BEARING CARRIER ASSEMBLY	1		
68A	22	98727	GREASE FITTING W/GREASE	2		
69	31	30956	ROLLER BEARING, BEARING	1	W/GREASE FITTING	
70	26	76868	OIL SEAL, BEARING CARRIER	1		
70A	26	70081	OIL SEAL, BEARING CARRIER	1		
71	28	30281	KEY, LOCATING - BEARING CARR	1		
72	14	52700	TAB WASHER, GEAR HOUSING	1		
73		52699	COVER, GEAR HOUSING	1		
74		31640A 1	TRIM TAB, GEAR HOUSING	1		
75	10	66024	SCREW, TRIM TAB TO GEAR H	1		
76	12	45176	WASHER, DRIVE SHAFT HOUSIN	2		
77	11	34933	NUT, DRIVE SHAFT HOUSING S	2		
78	10	65210	SCREW, GEAR HOUSING (1")	1		
79		75282	THRUST HUB	1		
82	14	31210	TAB WASHER, PROPELLER NUT	1		
83	11	52707	PROPELLER NUT	1		
-	27	73645A32	GASKET SET			