



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	833	1688A 1	CYLINDER BLOCK AND CRANCA	1,1		
1	833	1919A 3	CYLINDER BLOCK AND CRANCA	1,1		
2	17	20032	PIN, DOWEL - CYLINDER BLOC	3,3		
3	223	26348	BUSHING, CRANKCASE - COWI	2,2		
4	16	21831	STUD, CARBURETOR MOUNTI	6,6		
5	17	20033	PIN, DOWEL - CRANCASEE TO	2,2		
6	16	26133	STUD, CRANKCASE TO DRIVE	2,2		
7	16	26135	STUD, CYLINDER BLOCK TO D	4,4		
8	16	26134	STUD, CYLINDER BLOCK TO D	2,2		
9	10	29877	SCREW, CRANKCASE CYLINDER	3,3		
9	10	26132	SCREW, CRANKCASE TO CYLINC	2,2		
10	10	21574	SCREW, CRANKCASE TO CYLINC	4,4		
10	10	22040	SCREW, CRANKCASE TO CYLINC	17,17		
11	11	29250	NUT, CRANKCASE FASTENING S	26,26		
12		26551	BRACKET, CLAMP EXTENSION	2,2		
13	10	20089	SCREW, MAIN BEARING LOCKIN	3,3		
14	10	20359	SCREW, CENTER MAIN BEARIN	2,2		
15	14	20091	TAB WASHER, BEARING LOCKIN	5,5		
16	1125	1675A 1	END CAP ASSEMBLY, UPPER	1,1		
17	26	29476	OIL SEAL	1,1		
18	25	20081	"O" RING	1,1		
19	30	20080	BEARING, BALL	1,1		
20	15	20082A 1	SHIM, END CAP TO CRANKCASE	AR,AR		
21	10	30225	SCREW, END CAP MOUNTING	4,4		
22	1126	1751A 1	END CAP ASSEMBLY, LOWER	1,1		
23	26	29476	OIL SEAL, UPPER	1,1		
24	26	29478	OIL SEAL, LOWER	1,1		
25	25	20081	"O" RING	1,1		
26	30	20080	BEARING, BALL	1,1		
27	21	28481A 1	CHECK VALVE ASSEMBLY, ENC	1,1		
28	15	20085A 1	SHIM, END CAP TO CRANKCASE	AR,AR		
29	10	30225	SCREW, END CAP MOUNTING	3,3		
30	27	30013	GASKET, CYLINDER BLOCK TO K	1,1		
31		30066	PLATE, EXHAUST MANIFOLD	1,1		
32	27	30012	GASKET, MANIFOLD PLATE TO C	1,1		
33		29888	COVER, EXHAUST MANIFOLD	1,1		
34	10	28667	SCREW, MANIFOLD COVER MOL	23,23		
35	54	26519	CLAMP, SPARK PLUG LEADS TO	3,3		
36		30109	GROUND STRAP ASSEMBLY, CY	1,1		
37		30000	SWITCH, MERCURY	1,1		
38	54	22875	CLAMP, MERCURY SWITCH HOL	1,1		