



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1575	4971A 5	DRIVE SHAFT HOUSING ASSEMBLY	1	UNITED STATES 3865694 AND I	
1	1573	4933A 3	DRIVE SHAFT HOUSING ASSEMBLY	1	UNITED STATES 3865694 AND I	
1	1575	5240A 4	DRIVE SHAFT HOUSING AUTHORITY	1	UNITED STATES 3865695 AND I	
1	1573	5239A 4	DRIVE SHAFT HOUSING ASSEMBLY	1	UNITED STATES 3865695 AND I	
2	16	56295	STUD, DRIVE SHAFT HOUSING	2		
3	19	64649	PLUG, PLASTIC - TRIM TAB SCREW	1		
4	16	34378	STUD, DRIVE SHAFT HOUSING	7		
5		37417	COVER, TRIM - DRIVE SHAFT HC	1		
6	10	57807	SCREW, TRIM COVER TO BOTTOM	4		
7	25	57806	GROMMET, TRIM COVER SCREW	4		
7A		46933A 2	GROUND STRAP ASSEMBLY, TRIM	2		
7B	10	62568	SCREW, GROUND STRAP ATTACHMENT	2		
8	32	62864	TUBE, WATER INLET - SHORT SHAFT	1		
9		62863	TUBE, EXHAUST - - SHORT SHAFT	1	UNITED STATES 3865694 AND I	
9		65370	TUBE, EXHAUST - - SHORT SHAFT	1	UNITED STATES 3865695 AND I	
8	32	60897	TUBE, WATER INLET - LONG SHAFT	1		
9		60435	TUBE, EXHAUST - - LONG SHAFT	1	UNITED STATES 3739627 AND I	
9		65369	TUBE, EXHAUST - - LONG SHAFT	1	UNITED STATES 3739628 AND I	
9A		65638	BOOT, EXHAUST TUBE	2	UNITED STATES 3739628 AND I	
10	10	28636	SCREW, EXHAUST TUBE TO EXHAUST	2	UNITED STATES 3865694 AND I	
11	13	26992	LOCKWASHER, EXHAUST SCREW	2	UNITED STATES 3865694 AND I	
12	27	64175	GASKET, DRIVE SHAFT HOUSING	1	UNITED STATES 3865694 AND I	2
12	27	66335	GASKET, DRIVE SHAFT HOUSING	1	UNITED STATES 3865695 AND I	3,4
13		52887	GUIDE, PUSH ROD - REVERSE LOCK	1		
14		47591	ROD, PUSH - REVERSE LOCK (SHORT)	1		
14		47558	ROD, PUSH - REVERSE LOCK (LONG)	1		
15	11	47661	NUT, JAM - PUSH ROD	1		
16		47559	YOKE, PUSH ROD	1		
17	17	39023	PIN, PUSH ROD TO REVERSE LOCK	1		
18	18	25191	COTTER PIN, PUSH ROD PIN	1		
19		37398	MOUNT, RUBBER - UPPER	2		
20	12	47840	WASHER, RUBBER - UPPER MOUNT	2		
21	12	31263	WASHER, UPPER MOUNT BOLT	2		
22	11	34933	NUT, UPPER MOUNT BOLT	2		
23		54140	MOUNT, RUBBER - LOWER	2		
24	10	49318	SCREW, UPPER MOUNT (5 1/2")	2		
25	12	49339	WASHER, MOUNT SCREW	2		
26	11	25096	NUT, MOUNT SCREW	2		
27		25067	BUMPER, RUBBER - MOUNTING	2		
28	11	34933	NUT, GEAR HOUSING AND DRIVE	2		
29	12	46176	WASHER, GEAR HOUSING TO DRIVE	2		