



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	19	45907	PLUG, FLYWHEEL PULLER THRE	1		
2	11	52901	NUT, FLYWHEEL	1		
3	12	68229	WASHER, FLYWHEEL NUT	1		
4	225	2494A27	FLYWHEEL ASSEMBLY, COMPLE	1	UNITED STATES 3865694 AND I	
4	225	2494A30	FLYWHEEL ASSEMBLY, COMPLE	1	UNITED STATES 3865695 AND I	
5	10	32417	SCREW, FLEXIBLE PLATE TO FL	8		
6	10	49006	SCREW, PLATE/HUB TO FLEXIBI	8	UNITED STATES 3865694 AND I	
6	10	38398	SCREW, PLATE/HUB TO FLEXIBI	8	UNITED STATES 3865695 AND I	
7	17	26618	PIN, DOWEL - PULLEY TO FLYWI	1		
8		29788	FLANGE, FLYWHEEL PULLEY	1		
9		30306	PULLEY, FLYWHEEL	1		
10		29787	HUB, FLYWHEEL PULLEY	1		
11	398	4792	STATOR ALTERNATOR	1	UNITED STATES 3865694 AND I	
11	398	5232	STATOR ALTERNATOR	1	UNITED STATES 3865695 AND I	
13	10	63136	SCREW, STATOR TO UPPER EN	4		
14	54	22627	CLIP, STATOR LEAD FASTENING	2	UNITED STATES 3865694 AND I	
14	54	22875	CLIP, STATOR LEAD FASTENING	2	UNITED STATES 3865695 AND I	
15	10	62568	SCREW, STATOR LEAD FASTEN	2		
16		69205	"D" WASHER, CLIP FASTENING :	2		

