



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	184	1910A 2	COWL FRONT COVER ASSEMBL	1 1, 1 1		
2		26183A 5	EMBLEM, FRONT COVER	1,1		
3	10	29226	SCREW, BRACKET TO FRONT	2,2		
4	13	26995	LOCKWASHER, BRACKET FAS	2,2		
5	11	26419	NUT BRACKET FASTENING SC	2,2		
6		29345	BUMPER, RUBBER-FRONT COV	2,2		
7		32362	KNOB, COWL FRONT COVER F.	1,1		
8	12	30771	WASHER, COVER FASTENING	1,1		
9	12	26825	WASHER, COVER FASTENING	2,2		
10	24	30772	SPRING, TENSION-FASTENING	1,1		
11	17	29077	ROLL PIN, TENSION SPRING T	1,1		
12		31089	STRIP, SOUND ABSORBING	2,2		
13	194	1942A 3	WRAP AROUND COWL ASSEMBL	1,		
13	194	1942A 5	WRAP AROUND COWL ASSEMBL	,1		
14		30412	HANDLE, COWL LATCH	3,3		
15	53	21058	"E" RING, COWL LATCH HINGE	6,6		
16	17	21057	PIN, HINGE-COWL LATCH HAN	6,6		
17		30414	SWIVEL, COWL LATCH	3,3		
18		30413	HOOK, COWL LATCH FASTENIN	3,3		
19		30021	BLANKET, SOUND ABSORBING	1,1		
20	37	31885	DECAL, WRAP AROUND COWL	1,		
21	37	31884	DECAL, WRAP AROUND COWL	1,		
22	37	31883	DECAL, WRAP AROUND COWL	1,		
20	37	33679	DECAL, WRAP AROUND COWL	,1		
21	37	33678	DECAL, WRAP AROUND COWL	,1		
21	92	25234	GLU,ADHESIVE-BLANKET FASTE	1,1		
21	92	27109	ADHESIVE COMPOUND ( 3 1/2 O	1,1		