



				Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote	
1	182	1895A 2	TOP COWL ASSEMBLY	1,1			
2	16	20353	STUD, FRONT-TOP COWL TO C	2,2			
3	25	20116	GROMMET, CHOKE KNOB	1,1			
4		31476	REVEAL, AIR INTAKE	1,1			
5	10	30841	SCREW, REVEAL TO TOP COWL	2,2			
6	13	26996	LOCKWASHER, REVEAL TO TOP	2,2			
7		29947	SCREEN, VENT-TOP COWL	1,1			
8	10	29221	SCREW, VENT SCREEN TO TOP	2,2			
9		29981A 1	PLATE ASSEMBLY, COWL MOUN	1,			
9		31298A 1	PLATE ASSEMBLY, COWL MOUN	,1			
10	16	20353	STUD, REAR-TOP-COWL TO CC	1,1			
11	10	31299	SCREW, PLATE ASSEMBLY TO T	3,3			
12	12	20028	WASHER, TOP COWL STUD (1 1,	2,2			
13	12	20346	WASHER, TOP COWL STUD (3/4	4,4			
14	12	20583	WASHER, TOP COWL STUD (1/3	AR,AR			
15	11	20361	NUT, TOP COWL FASTENING	4,4			
16		30755	RETAINER, STARTER SPRING	1,1			
17	24	30753	SPRING, STARTER REWIND	1,1			
18	23	30754	BUSHING, SPRING GUIDE	1,1			
19	50	30749	SHEAVE ASSEMBLY	1,1			
20		20162	PAWL, STARTER	3,3			
21	13	29402	WASHER, WAVE-STARTER PAW	3,3			
22	23	30752	BUSHING, NYLON-SHEAVE SHAF	1,1			
23	23	30759	SPACER, SHEAVE SHAFT	1,1			
24	12	26180	WASHER, SHEAVE SHAFT TO S1	1,1			
25	13	20160	WASHER, WAVE-WASHER TENS	1,1			
26	12	30758	WASHER, EQUALIZING RING-ST.	1,1			
27		30757	PLATE, RETAINER-STARTER PA	1,1			
28		30756	SHAFT, SHEAVE	1,1			
29	14	20165	TAB WASHER, SHEAVE SHAFT	1,1			
30	11	20166	NUT, SHEAVE SHAFT (LEFT HAN	1,1			
31	50	28985A 1	STARTER CABLE ASSEMBLY	1,1			
32		28747	HANDLE, STARTER CABLE	1,1			
33		28748	RETAINER, STARTER CABLE AN	1,1			
34	10	32063	SCREW, DRIVE-PLATE TO TOP C	3,3			
35		30045	PLATE, ROPE GUIDE SEE NOTE	1,1			
34	10	35881	SCREW,DRIVE-PLATE TO TOP C	,3			
35		35880	PLATE, ROPE GUIDE SEE NOTE	,1			
36		31463	HANDLE, CHROME-TOP COWL	1,1			
37		31487	HANDLE ASSEMBLY, INSIDE - TC	1,1			
38		25495	PAD, RUBBER TOP COWL HAND	1,1			