



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		58888A	4 FUEL PUMP ASSEMBLY	1		
2	21	30430A	5 CHECK VALVE ASSEMBLY	1		
3		55278A	2 DIAPHRAGM KIT	1		2,3
4			GASKET, FUEL PUMP	2		2,3
5			GASKET, CHECK VALVE TO HOU	2		2,3
6		23004	RETAINER, CHECK VALVE	1		
7	10	20037	SCREW, RETAINER TO HOUSIN	2		
8	10	27281	SCREW, PUMP MOUNTING (1 3/	3		
9	32	55827A	1 FUEL LINE ASSEMBLY, PUMP TC	1		
10	22	59351	ELBOW, UPPER CARBURETOR	1		
11	22	30175	SLEEVE, UPPER CARBURETOR	1		
12	22	30177	NUT, UPPER CARBURETOR ELB	1		
13	32	59352	FUEL LINE, CARBURETOR TO C/	1		
14	22	30468	CONNECTOR, FUEL PUMP	2		
15	22	30175	SLEEVE, CONNECTOR	1		
16	22	30177	NUT, CONNECTOR	1		
17	32	55829	FUEL LINE, ADAPTOR TO UPPEF	1		
18		30186	ADAPTOR, CHECK UNIT (FUEL LI	1		
19		30187	STEM, CHECK UNIT ADAPTOR	1		
20	24	30189	SPRING, ADAPTOR STEM	1		
21	25	20415	"O" RING, ADAPTOR STEM	1		2,3
22		30188	CUP WASHER, ADAPTOR	1		
23	10	31471	SCREW, ADAPTOR TO BOTTOM	1		
23	10	37990	SCREW, ADAPTOR TO BOTTOM	2		
24	11	46887	NUT, ADAPTOR FASTENING SCF	2		