



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		58888A	FUEL PUMP ASSEMBLY	1		
2	21	30430A	CHECK VALVE ASSEMBLY	1		
3		55278A	DIAPHRAGM KIT	1		4
4			GASKET, FUEL PUMP	2		4
5			GASKET, CHECK VALVE TO HOU	2		4
6		23004	RETAINER, CHECK VALVE	1		
7	10	20037	SCREW, RETAINER TO HOUSIN	2		
8	10	27281	SCREW, PUMP MOUNTING (1 3/	3		
9	22	64704	FITTING, FUEL PUMP (OUTLET)	1		
10	54	68424	CLAMP, FUEL LINE ATTACHING	8		
11	32	63146	FUEL LINE, FUEL PUMP TO FILT	1		
12		70929	BASE, FUEL PUMP	1		
13	10	70939	SCREW, BASE TO TRANSFER PC	1		
14	12	20533	WASHER, BASE SCREW	1		
15	35	59072	SCREEN, FILTER - INLET	1		4
16	25	47386	"O" RING, COVER TO HOUSING	1		4
17		59071	COVER, FUEL INLET	1		
18	27	25848	GASKET, NYLON - FILTER COVER	1		4
19	10	37370	SCREW, COVER TO FUEL PUMP	1		
20	22	64705	FITTING, FILTER BASE	1		
21	32	63146	FUEL LINE, FILTER COVER TO C/	1		
22	22	66328	FITTING, TEE - UPPER CARBURE	1		
23	32	63146	FUEL LINE, CARBURETOR TO C/	1		
24	22	64704	FITTING, ELBOW - LOWER CARB	1		
25	22	64705	FITTING, FUEL LINE TO FUEL PU	1		
26	32	63146	FUEL LINE, ADAPTOR TO FUEL F	1		
27	22	63981	ELBOW, FUEL LINE TO ADAPTOR	1		
28		30188	CUP WASHER, ADAPTOR	1		
29	25	20415	"O" RING, ADAPTOR STEM	1		4
30	24	30189	SPRING, ADAPTOR STEM	1	UNITED STATES 4153349 AND I	
31		30187	STEM, CHECK UNIT ADAPTOR	1	UNITED STATES 4153349 AND I	
32		30186	ADAPTOR, CHECK UNIT (FUEL LI	1	UNITED STATES 4153349 AND I	
30	24	23067	SPRING, ADAPTOR STEM	1	UNITED STATES 4153350 AND I	
31		23069	STEM, CHECK UNIT ADAPTOR	1	UNITED STATES 4153350 AND I	
32		22833	ADAPTOR, CHECK UNIT (FUEL LI	1	UNITED STATES 4153350 AND I	
33	10	69029	SCREW, ADAPTOR TO BOTTOM	2		
34	11	35045	NUT, ADAPTOR FASTENING SCF	2		