



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	421	5275	CRANKSHAFT	1	UNITED STATES 5306000 AND I	
2	26	72793	SEAL, CRANKSHAFT	1	UNITED STATES 5306000 AND I	
1	421	7271A 2	CRANKSHAFT ASSEMBLY	1	UNITED STATES 5524569 AND I	
3		79952A 1	CARRIER ASSEMBLY	1	UNITED STATES 5524569 AND I	
4	12	79960	WASHER, FELT	1	UNITED STATES 5524569 AND I	
5	28	20094	KEY, CRANKSHAFT	1		
6	550	8122A 5	MAIN BEARING ASSEMBLY (VAL)	1		
7	17	20032	DOWEL PIN, MAIN BEARING	2		
8	17	65855	DOWEL PIN, REED LOCATING	8		
9	10	56781	SCREW, MAIN BEARING CLAMPI	2		
10	17	20032	DOWEL PIN, MAIN BEARING TO	1		
11	34	31942A 1	REED SET, MATCHED - MAIN BE	1		
12	34	20053	REED STOP, MAIN BEARING REE	4		
13	10	27304	SCREW, REED STOP MOUNTING	4		
14	608	7395A 2	CONNECTING ROD ASSEMBLY	2		
15	10	87374	SCREW, CONNECTING ROD	4		
16	29	26815	NEEDLE BEARING, CRANKPIN	58		
17	11	20061	NUT, CONNECTING ROD SCRE	4		
18	12	65967	WASHER, NEEDLE BEARING R	4		
19	29	31505	NEEDLE BEARING, PISTON PIN	40		
20	719	7391A 3	PISTON AND PISTON PIN ASSEM	2		
21	40	21666	LOCK RING, PISTON PIN	4		
22	39	21665A12	PISTON RING	1		