



2650

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		835385T01	INTAKE MANIFOLD	1		
2	27	853525001	GASKET	1		2
3	18	815026	COTTER PIN	2		
4	10	853531001	BOLT	6		
5	12	895106	WASHER	6		
6	54	95395	CLAMP	1		
7	27	835383001	INSULATOR, Carburetor	2		2
8		853526001	INSULATOR	1		
9		835386001	AIR BOX	1		
10	25	825057003	O-RING	1		2
11	10	855809	BOLT, (M6 x 100)	2		
12	12	895106	WASHER	2		
13	32	851848004	HOSE, Breather	1		
14		803529T03	FUEL PUMP	1		
15	21	851812003	CHECK VALVE, (Black)	1		7
16	21	851812004	CHECK VALVE, (White)	1		7
17	27	855569003	GASKET	1		7
18		853731003	DIAPHRAGM	1		7
19	10	895107	SCREW	2		
20	10	895107001	SCREW	4		
21	25	803513	O-RING	1		2
22	10	855544	SCREW, (M6 x 25)	2	SN# 0R052327 & Below	
22	10	855544021	SCREW	2	SN# 0R052328 & Up	
23	32	851848005	HOSE, Fuel	1		
24	32	851848006	HOSE, Fuel	1		
25	35	16248	FILTER, Fuel	1		
26	54	95395	CLIP	4		
27	32	895108	PROTECTIVE TUBING	2		
28	32	895108001	PROTECTIVE SLEEVE	1	(Electric Remote Control)	
29	32	895109	HOSE, Overflow	1		
-	27	835427A04	POWERHEAD GASKET SET	1		
-	21	851812A01	DIAPHRAGM KIT	1		