



 4 Cycle Oil (92-828000A12)

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		825439	VALVE-INTAKE	2		2
2		825440	VALVE-EXHAUST	2		2
3		825441	WASHER	4		2
4	26	822647	SEAL	4		3,2
5	24	825442	SPRING-INNER	4		2
6		827747	RETAINER	2		2
7	28	822651	COTTER PIN-VALVE	4		2
8		825445	LIFTER-VALVE	2		2
9		825447A 1	ARM-ROCKER VALVE	4		2
10	10	825448	SCREW-VALVE ADJUSTING	4		2
11	11	825449	NUT	4		2
12	24	825452	SPRING	3		2
13		825451	COLLAR	3		2
14	24	825453	SPRING	1		2
15		825450	SHAFT-ROCKER	2		2
16		825443	RETAINER	2		2
-	61	822775A 7	POWERHEAD	1		
-	27	825847A95	GASKET SET	1		