



Parts List					
Ref	Class	Part	Description	Qty	Footnote
	1666	8833A 9	GEAR HOUSING, COMPLETE (SH)	1	
	1666	8833A10	GEAR HOUSING, COMPLETE (LO)	1	
	1666	8833A11	GEAR HOUSING, COMPLETE (SH)	1	
	1666	8833A12	GEAR HOUSING, COMPLETE (LO)	1	
1	1666	8833A 1	GEAR HOUSING (BLACK)	1	
1	1666	8833A 4	GEAR HOUSING (GRAY)	1	
41	10	13403	SCREW	1	
42	10	13402	SCREW	2	
43	31	41347A 1	ROLLER BEARING	1	
44	43	41371A 1	FORWARD GEAR	1	
45	23	41367	BUSHING	1	
46		813139	CAM FOLLOWER	1	
47	53	32449	RETAINING RING	1	
48	52	43217	CLUTCH	1	
49	17	30535	CROSS PINT	1	
50	24	42204	SPRING	1	
51	44	41370	PROPELLER SHAFT	1	
52	43	44115	REVERSE GEAR	1	
53		42144A 2	BEARING CARRIER	1	
54	25	33145	O-RING	1	2,17
55	23	41368	BUSHING	1	
56	26	66022	OIL SEAL	1	17
57		42037	THRUST HUB	1	
58		42201	CAP	1	
59	48	42522A12	PROPELLER (9" X 9")	1	
59	48	17874A12	PROPELLER (9" X 10-1/2")	1	
59	48	42524A12	PROPELLER (SAILPOWER)	1	
60	23	42091	SPACER	1	
61	11	13914	PROPELLER NUT	1	
.	27	42364A92	ENGINE/POWERHEAD GASKET	1	
.	26	41365A 3	DRIVESHAFT HOUSING SEAL KI	1	