



15211

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14360A71	FUEL PUMP ASSEMBLY	1		
2		42909A 4	DIAPHRAGM KIT	1		2
3		NSS	NOT SOLD SEPARATE, Check	2		7
4		NSS	NOT SOLD SEPARATE, Gasket	1		7
5		NSS	NOT SOLD SEPARATE, Diaphragm	1		7
6		NSS	NOT SOLD SEPARATE, Gasket	1		7
7		NSS	NOT SOLD SEPARATE, Spring	1		7
8		NSS	NOT SOLD SEPARATE, Cap	1		7
9		NSS	NOT SOLD SEPARATE, Check	2		7
10		NSS	NOT SOLD SEPARATE, Retainer	2		7
11		NSS	NOT SOLD SEPARATE, Spring	1		7
12		NSS	NOT SOLD SEPARATE, Cap	1		7
13	27	98769 1	GASKET	1		2
14		98768	BASE	1		
15		98775A 1	PLATE	1		
16	21	42481	CHECK VALVE, Oil Injection	1		
17	22	19688	FITTING	1		
18	10	40093 40	SCREW	2		
19	10	40057134	SCREW, (M6 X 50)	2		
20	32	99129 76	TUBING	2		
21	35	816296 1	FUEL FILTER	1		
22	54	816311T	CABLE TIE, (8.00 Inch)	AP		
23	22	816856A 3	FUEL CONNECTOR, Plastic	1		
24	25	14509 1	GROMMET	1		
25	10	40106 35	SCREW, (M6 x 35)	1		
26		43739	ENRICHNER VALVE	1		
27	32	14301 65	TUBING, (38.00 Inch)	2		
28	54	18887	CLAMP	1		
29	10	821273 35	SCREW, (M8 x 35)	1		
30	22	64705	FITTING	1	(To Crankcase)	
31	32	99127109	FUEL LINE, (57.00 Inches Bulk)	1		
32	22	56800	PLUG, Pipe (.0625-27), Non Oil Inje	1		
33	32	19017A 1	FUEL LINE	1	(To Carburetor)	
34	54	13791	CLAMP, (15.7), Old Design, New D	4		
-	27	43004A90	GASKET SET	1		
-		42909A 4	FUEL PUMP DIAPHRAGM KIT	1		