



**Quicksilver Lubrication/Sealant  
 Application Points**

 Loctite 271 (Obtain Locally)

EXHAUST PLATE

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		42954A 5	EXHAUST PLATE ASSEMBLY	1		
2	17	23784	DOWEL PIN	5		
3	10	40011151	SCREW (M8 X 35)	2		
3	10	40011158	SCREW (M8 X 70)	1		
4		44344 2	MOUNT	1	(NON OIL INJECTION)(LL)	
4		42949 2	MOUNT	1	(OIL INJECTION) (JET 65)	
5	10	40107 50	SCREW (M8 X 50)	4		
6	10	42974	SCREW (M12 X 175)	2		
7	12	93416 1	WASHER	2		
8	12	28421	WASHER	2		
9	11	90099	NUT	2		
10	27	43008 6	GASKET	1		4
11		42966 4	EXHAUST TUBE	1		
11		42966A 1	EXHAUST TUBE	1	(BELGIUM)(INCLUDES RESTRIC	
12	10	40011151	SCREW (M8 X 35)	6		
13		42962	SEAL-EXHAUST TUBE	1		
14	25	89417 1	GROMMET	1		
15	32	824660 1	WATER TUBE (13-1/4 IN.)	1		
15	32	824660 2	WATER TUBE (15-3/4 IN.)	1		
15	32	824660 3	WATER TUBE (18-1/4 IN.)	1		
16		824661	CLAMP	1		
17		814080	SEAL (UPPER)	1		
18	10	40107 50	SCREW (M8 X 50)	2		
19		42953A 5	BRACKET ASSEMBLY (LOWER)	1	(BLACK)	
19		42953A 6	BRACKET ASSEMBLY (LOWER)	1	(GRAY)	
19		42953A 7	BRACKET ASSEMBLY (LOWER)	1	(TRACKER-GRAPHITE GRAY)	
20		43405	SEAL	1		
21	25	12602 1	GROMMET	1	(POWER TRIM - S/N-0G360002 {	
21	25	19564	GROMMET	1	(NON POWER TRIM/MANUAL T	
22	25	19565	GROMMET	1	(POWER TRIM - S/N-0G360003 {	
23	10	817427 50	SCREW (M8 X 50)	3		
24	23	48237	BUSHING	1		
25		79932A 9	SHIFT SHAFT ASSEMBLY	1	(UPPER - ELECTRIC) (S/N-USA-C	
25		79932A19	SHIFT SHAFT ASSEMBLY	1	(UPPER - ELECTRIC) (S/N-0G590	3
25		79932A13	SHIFT SHAFT ASSEMBLY	1	(UPPER - MANUAL)	
26		42912A 1	SHIFT LINK	1	(S/N-USA-0G589999/BEL-99730	
26		42912A 3	SHIFT LINK	1	(S/N-USA-0G590000/BEL-99731	3
27	23	48475	BUSHING	2		
28	11	826833 6	NUT	1		
29	23	813745	SPACER	1	(LONG)	1
29	23	11389	SPACER	1	(X-LONG)(LL)	