



| Parts List |       |          |                            |     |         |          |
|------------|-------|----------|----------------------------|-----|---------|----------|
| Ref        | Class | Part     | Description                | Qty | Comment | Footnote |
| 1          | 19    | 45907    | PLUG, FLYWHEEL             | 1   |         |          |
| 2          |       | 42956A   | COVER ASSEMBLY, FLYWHEEL   | 1   |         |          |
| 3          |       | 79022    | MARKER, TIMING             | 1   |         |          |
| 4          | 10    | 37572    | SCREW, TIMING MARKER       | 2   |         |          |
| 5          | 12    | 72761    | WASHER, TIMING MARKER SC   | 2   |         |          |
| 6          | 11    | 42979    | NUT, FLYWHEEL              | 1   |         |          |
| 7          | 12    | 68229    | WASHER, FLYWHEEL           | 1   |         |          |
| 8          | 261   | 9008A16  | FLYWHEEL ASSEMBLY          | 1   |         |          |
| 9          | 398   | 8778A10  | STATOR ASSEMBLY            | 1   |         |          |
| 10         | 10    | 40073 25 | SCREW, STATOR              | 4   |         |          |
| 11         |       | 99021A 3 | TRIGGER ASSEMBLY           | 1   |         |          |
| 12         | 50    | 66015    | STARTER MOTOR              | 1   |         |          |
| 13         |       | 56703    | COLLAR, STARTER MOTOR      | 2   |         |          |
| 14         |       | 57247    | STOP, RUBBER-STARTER MOTC  | 2   |         |          |
| 15         | 84    | 93388A 1 | WIRE, STARTER MOTOR TO PL  | 1   |         |          |
| 16         | 10    | 69035    | SCREW, WIRE TO STARTER MO  | 1   |         |          |
| 17         | 84    | 88439A20 | WIRE, STARTER MOTOR (BLACK | 1   |         |          |
| 18         | 13    | 26992    | LOCKWASHER, STARTER MOTO   | 1   |         |          |
| 19         | 11    | 64015    | NUT, STARTER MOTOR TERMIN  | 1   |         |          |