



15174

				Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote	
1		12022A 4	BRACKET ASSEMBLY, Black	1			
1		12022A 5	BRACKET ASSEMBLY, Gray	1			
2	79	12012A 1	TACHOMETER ASSEMBLY	1			
3	11	11316 1	NUT	4			
4	16	12782	STUD, Bracket	2			
5		15126	SPACER	1			
6	14	12080	TAB WASHER	2			
7	11	40020 16	NUT	2			
8		12105	GROMMET	1			
9	84	12649A 2	HARNES ASSEMBLY	1			
10	87	88107	KEY SWITCH	1			
11	11	93543	NUT, Special, Key Switch	1			
12		12015	COVER, Bracket	1			
13	10	72169	SCREW, (10-24 X .50), Bracket Co	6			
14	19	12014	PLUG	1			
15	87	11083A 4	SWITCH ASSEMBLY, Stop	1			
16		15920A54	LANYARD ASSEMBLY	1			
17		12044	RETANER, Stop Switch	1			
18	10	40003 58	SCREW, (M8 x 50), Shift Lever	1			
19	14	42981	TAB WASHER	3			
20	23	42992 1	BUSHING	2			
21		12021 1	SHIFT LEVER	1			
22		12016A 1	DETENT ASSEMBLY	1			
23	16	58152	STUD, (.375-24 x 1.125), Shift Levr	1			
24		98530	KNOB, Shift Lever	1			
25		49563 1	SHIFT ROD	1			
26		48419	ROD END	1			
27	23	26856	BUSHING	1			
28	12	35950	WASHER, Shift Rod	1			
29	18	25191	COTTER PIN, Shift Rod	1			
30	87	93479A 7	NEUTRAL START SWITCH	1			
31		12609	BRACKET, Primary	1			
32		12610	BRACKET, Switch	1			
33	10	90342	SCREW, (#4-40 x .630), Switch To	2			
34	11	24832	NUT, (#4-40), Switch Screw	2			
35	10	57583	SCREW, (#8-32 x .375), Bracket T	2			
36	12	20878	WASHER, Bracket Screw	2			
37	11	26419	NUT, (#8-32), Bracket Screw	2			
38	10	40001134	SCREW, (M8 x 25), Primary Bracke	2			
39		89491 1	KEY	1			
40		89491 2	KEY, Location	1			