



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	2115	8963A 1	COWL, BOTTOM (BLACK)	1		
1	2115	8963A 2	COWL, BOTTOM (GRAY)	1		
2		52862A 2	DRIP TRAY ASSEMBLY, BOTTOM	1		
3		37940	SOUND PAD, DRIP TRAY	1		
4	10	48408	SCREW, DRIP TRAY TO BOTTOM	4		
5	32	34395A 1	HOSE, DRIP TRAY TO BOTTOM (1		
6		76369	SPACER, BOTTOM COWL	1		
7	10	35519	SCREW, SPACER TO BOTTOM C	2		
8		39616	BOOT, CONTROL CABLES - BOT	1		
9		37637	BOOT, FUEL CONNECTOR - BOT	1		
10	32	99127109	HOSE, TELL TALE (21-1/2")	1		
11		52889	NOZZLE, TELL TALE HOSE TO B	1		
12	10	48408	SCREW	1	TELL TALE NOZZLE TO BOTTO	
13	22	78279	ELBOW, TELL TALE HOSE TO Cy	1		
14		60304A54	SHIFT SHAFT ASSEMBLY, UPPEF	1		
15	23	26856	BUSHING, SHIFT SHAFT	1		
16		73402	SHIFT LINK	1		
17	12	35462	WASHER, LINK ROD	2		
18	11	36069	NUT, LINK ROD	2		
19	13	29720	WASHER, WAVE - LINK ROD	1		
20	24	20099	SPRING, LINK ROD TO GUIDE BL	1		
21		37896	GUIDE BLOCK, LINK ROD	1		
22		52732A 6	BRACKET, ANCHOR - CONTROL	1		
23		98889	LATCH NEW STYLE	1		
24	10	42975	SCREW, LATCH NEW STYLE	2		
25		39618	LEVER, NYLON - SHIFT CABLE LI	1		
26	17	47175	PIN	3	LOCKING LEVER AND COVER F	
27		90211	COVER, NYLON - SHIFT CABLE O	1		
28		65799T	LINK, LOCKING LEVER TO COVER	1		
29		39519	CAP, BARREL RETAINER - ANCH	1		
30	10	35386	SCREW	3	ANCHOR BRACKET TO CYLINDE	
31		52100	WEAR PLATE, LINK ROD	1		
32		38279	LATCH	1	CONTROL CABLE FASTENING -	