



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		13527A 1	FUEL PUMP ASSEMBLY	1		
2	21	30430A14	CHECK VALVE ASSEMBLY	1		
3		89031A 3	DIAPHRAGM ASSEMBLY	1		13
4			GASKET, FUEL PUMP	1		13
5			GASKET, PULSE CHAMBER	1		13
6			GASKET, FUEL PUMP	2		13
7			GASKET, CHECK VALVE TO	2		13
8	35	59072	SCREEN, FUEL INLET	1		13
9	25	35480	"O" RING, FUEL INLET COV	1		13
10	25	38933	GASKET, COVER SCREW	1		13
11		23004	RETAINER, CHECK VALVE	1		
12	10	43723	SCREW, RETAINER	2		
13		86295	BASE, FUEL PUMP	1		
14		87990 1	PULSE CHAMBER, FUEL PUMP	1		
15	35	91078A 1	COVER, FUEL INLET	1		
16	10	89766	SCREW, FUEL FILTER COVEF	1		
17	22	64705	FITTING, INLET COVER	1		
18	10	F1979	SCREW, FUEL PUMP (1-1/2")	5		
19	13	26996	LOCKWASHER, FUEL PUMP SC	5		
20	22	19688	FITTING, FUEL OUTLET	1		
21		86026	RETAINER, SPRING	1		
22	24	86207	SPRING, COMPRESSION	1		
23		86252	CAP, SPRING END	1		
24	32	99127109	FUEL LINE, FUEL PUMP (w/O INI	4		
25	54	68424	CLAMP, FUEL LINE ATTACHING	10		
26	22	19688	FITTING, ELBOW - UPPER CARBI	1		
27	22	73318	TEE, FUEL LINE	1		
28	22	64706	FITTING, TEE - CENTER CARBUF	1		
29	22	19688	FITTING, ELBOW - LOWER CARB	1		
30	32	99127109	FUEL LINE, ADAPTOR TO FUEL F	1		
31	22	63981	ELBOW, FUEL LINE TO ADAPTOR	1		
32		30186	ADAPTOR, CHECK UNIT	1		
33		30187	STEM, CHECK UNIT ADAPTOR	1		
34	24	30189	SPRING, ADAPTOR STEM	1		
35	25	20415	"O" RING, ADAPTOR STEM	1		13
36		30188	CUP WASHER, ADAPTOR	1		
37	10	36154	SCREW, ADAPTOR TO BOTTON	2		
38	11	36069	NUT, ADAPTOR SCREW	2		
39	32	99127109	FUEL LINE -WITH INLINE FILTER	1		
40	54	68424	CLAMP, FUEL LINE -WITH INLINE	2		
41	25	16484	FUEL FILTER -WITH INLINE FILT	1		