



| Parts List | | | | | | |
|------------|-------|----------|-----------------------------|-----|----------------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| - | 1655 | 7333A24 | GEAR HOUSING ASSY, COMP. | 1 | THE ENCLOSED GEAR HOUSIN | |
| 1 | 1655 | 7333A23 | GEAR HOUSING ASSY | 1 | | |
| 49 | | 76039 | CAM, SHIFT | 1 | | |
| 50 | | 30625 | FOLLOWER, CAM | 1 | | |
| 51 | | 30624 | SLIDE, CROSS PIN | 1 | | |
| 52 | 24 | 30622 | SPRING, COMPRESSION - CAM | 1 | | |
| 53 | 15 | 30923A 1 | SHIM | AR | BEARING OUTER RACE TO HOUL | 5 |
| 54 | 31 | 30894A 1 | TAPERED ROLLER BEARING A | 1 | | |
| 55 | 31 | 30895 | BEARING, ROLLER - FORWARD | 1 | | |
| 56 | 43 | 68447 | FORWARD GEAR | 1 | | |
| 57 | 52 | 34239 | RATCHET, SLIDING GEAR | 1 | | |
| 58 | 17 | 30632 | PIN, CROSS - RATCHET TO PR | 1 | | |
| 59 | 24 | 30893 | SPRING, RETAINING - CROSS F | 1 | | |
| 60 | 44 | 52542 | SHAFT, PROPELLER | 1 | | |
| 61 | 43 | 76250 | REVERSE GEAR | 1 | | |
| 62 | 12 | 76805 | WASHER, THRUST | 1 | BEARING CARRIER TO GEAR H | |
| 63 | 25 | 29976 | "O" RING, BEARING CARRIER | 1 | | 4 |
| 64 | | 77520A 1 | BEARING CARRIER ASSEMBLY | 1 | | |
| 65 | 31 | 30956 | BEARING, ROLLER - BEARIN | 1 | | |
| 66 | 26 | 76868 | OIL SEAL, BEARING CARRIEF | 2 | | |
| 67 | 28 | 30281 | KEY, LOCATING - BEARING CA | 1 | | |
| 68 | 14 | 52700 | TAB WASHER, GEAR HOUSING | 1 | | |
| 69 | | 52699 | COVER, GEAR HOUSING | 1 | | |
| 70 | | 31640A 1 | TRIM TAB, GEAR HOUSING | 1 | | |
| 71 | 10 | 66024 | SCREW, TRIM TAB TO GEAR H | 1 | | |
| 72 | 12 | 45176 | WASHER | 2 | GEAR HOUSING TO DRIVE SHA | |
| 73 | 11 | 34933 | NUT | 2 | GEAR HOUSING TO DRIVE SHA | |
| 74 | 10 | 65210 | SCREW | 1 | GEAR HOUSING TO DRIVE SHA | |
| 75 | | 75282 | THRUST HUB | 1 | | |
| 76 | 14 | 31210 | TAB WASHER, PROPELLER NUT | 1 | | |
| 77 | 11 | 52707 | NUT, PROPELLER | 1 | | |
| - | 27 | 85653A79 | GASKET SET | | | |