



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1573	5239A 4	DRIVE SHAFT HOUSING ASSEM	1	
2	16	56295	STUD, DRIVE SHAFT HOUSING	2	
3	19	64649	PLUG, PLASTIC - TRIM TAB	1	
5		37417	COVER, TRIM - DRIVE SHAFT HC	1	
6	10	57807	SCREW, TRIM COVER TO BOTTC	4	
6A	25	92012	GROMMET, PLASTIC - TRIM COV	4	
6B		88238A 4	GROUND STRAP ASSEMBLY, TR	2	
6C	10	62568	SCREW, GROUND STRAP ATTACH	2	
7	32	60897	TUBE, WATER INLET	1	
8		78184	EXHAUST TUBE	1	
8A		65638	BOOT, EXHAUST TUBE	2	
11	11	69254	NUT, POWERHEAD STUDS (3/8-	2	
12	12	25970	WASHER, POWERHEAD STUDS	2	
14		52887	GUIDE, PUSH ROD	1	NOT USED WITH FULL POWER
15		47558	ROD, PUSH	1	NOT USED WITH FULL POWER
16	11	47661	NUT, JAM - PUSH ROD	1	NOT USED WITH FULL POWER
17		47559	YOKE, PUSH ROD	1	NOT USED WITH FULL POWER
14		92704	GUIDE, PUSH ROD	1	NOT USED WITH FULL POWER
15		92707	ROD, PUSH	1	NOT USED WITH FULL POWER
16	11	28770	NUT, JAM - PUSH ROD	2	NOT USED WITH FULL POWER
17		89813	YOKE, PUSH ROD	1	NOT USED WITH FULL POWER
19	18	25191	COTTER PIN, PUSH ROD	1	NOT USED WITH FULL POWER
20		75296	MOUNT, RUBBER - UPPER	2	
21	12	47840	WASHER, RUBBER - UPPER MOU	2	
22	12	31263	WASHER, UPPER MOUNT BOLT	2	
23	11	34933	NUT, UPPER MOUNT BOLT	2	
24		75299	MOUNT, RUBBER - LOWER	2	
25	10	49318	SCREW, LOWER MOUNT (5-1/2"	2	
26	12	49339	WASHER, LOWER MOUNT SCRE	2	
27	11	25096	NUT, LOWER MOUNT SCREW	2	
28		25067	BUMPER, RUBBER - LOWER MO	2	
30	11	34933	NUT, GEAR HOUSING STUDS	2	
31	12	45176	WASHER, GEAR HOUSING STUC	2	
32	11	29489	NUT, GEAR HOUSING STUDS	1	
33	12	45176	WASHER, GEAR HOUSING STUC	1	
34		35608	CLAMP, LOWER MOUNT	2	
35	24	35522	SPRING, TENSION - LOWER MO	4	
36	10	29256	SCREW, LOWER MOUNT CLAMP	4	
37		35474	COVER, LOWER MOUNT CLAMP	2	
38	11	35521	NUT, LOWER MOUNT CLAMP CC	2	
39	10	87884	SCREW, COVER TO LOWER CLA	2	