



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	2406	880894T01	CRANKSHAFT	1		5
2	26	804099003	OIL SEAL	1		2,5
3	26	804100003	OIL SEAL	1		2,5
4	31	804101T	BEARING	4	(Green)	5
4	31	804101T10	BEARING	4	(Blue)	5
4	31	804101T20	BEARING	4	(Red)	5
5	31	804102T	BEARING	5	(Yellow)	5
5	31	804102T10	BEARING	5	(Green)	5
5	31	804102T20	BEARING	5	(Blue)	5
5	31	804102T30	BEARING	5	(Red)	5
6	31	804103T	BEARING	1	(Green)	5
6	31	804103T10	BEARING	1	(Blue)	5
6	31	804103T20	BEARING	1	(Red)	5
7	2715	880895T02	PISTON/CONNECTING ROD ASS	4	(Standard)	5
7	2715	880895T03	PISTON/CONNECTING ROD ASS	AR	(.25mm O/S)	
8	10	804105	BOLT	2		5
9	39	880897T02	RING SET, Piston	1	(Standard)	5
9	39	880898T02	RING SET, Piston	AR	(.25mm Oversize)	
10	31	804106T01	BEARING	8	(Yellow)	5
10	31	804106T11	BEARING	8	(Green)	5
10	31	804106T21	BEARING	8	(Blue)	5
10	31	804106T31	BEARING	8	(Red)	5
11	28	804153	KEY	1		5
12	28	826100 1	KEY	1		
-	27	858732A03	GASKET SET, Powerhead	1		
-		881421T05	POWERHEAD ASSEMBLY	1		