



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1499	8710A 4	SWIVEL BRACKET ASSEMBLY (B)	1	
1	1499	8710A13	SWIVEL BRACKET ASSEMBLY (G)	1	
2	26	87735	OIL SEAL, SWIVEL BRACKET (L)	1	
3	23	67669	BUSHING, SWIVEL BRACKET - L	2	
4	25	33466	"O" RING, SWIVEL BRACKET -	1	13
5	23	67668	SPACER, SWIVEL BRACKET - L	1	
6	22	74036	FITTING, GREASE	2	
7	23	99608	BUSHING, SWIVEL BRACKET	2	
8		99661A 2	SWIVEL PIN AND STEERING ARM	1	
9	10	99621	SCREW, STEERING ARM TO UP	2	
10		75296	MOUNT, RUBBER - UPPER	2	
11	12	47840	WASHER, UPPER MOUNT BOLT	2	
12	12	31263	WASHER, UPPER MOUNT BOLT	2	
13	11	34933	NUT, UPPER MOUNT BOLT	2	
14		92876A 1	STEERING LINK ASSEMBLY	1	
15	10	14000	SCREW, STEERING LINK TO STE	1	
16	11	34863	NUT, STEERING LINK SCREW	2	
17	12	34931	WASHER, STEERING LINK TO S	2	
18	13	78854	WAVE WASHER, BOTTOM YOKE	1	
19		99644T	BOTTOM YOKE (BLACK)	1	
19		99644T 6	BOTTOM YOKE (GRAY)	1	
20	53	67684	RETAINING RING, BOTTOM YOK	1	
21	12	67670	WASHER, THRUST - SWIVEL BR	1	
22		43409T	REVERSE LOCK - NOT USED WIT	1	
23	11	35814	NUT	1	JAM - PUSH ROD - NOT USED w
24		99636	YOKE, PUSH ROD - NOT USED w	1	
25	24	44297	SPRING, PUSH ROD NUT	1	NOT USED WITH POWER TRIM
26	12	70132	WASHER	1	PUSH ROD - NOT USED WITH F
27		43414	PUSH ROD (LONG SHAFT)	1	NOT USED WITH POWER TRIM
28		92704	GUIDE, PUSH ROD	1	NOT USED WITH POWER TRIM
29	23	69132	BUSHING, REVERSE LOCK SHAF	2	NOT USED WITH POWER TRIM
30	17	99663	CLEVIS PIN, REVERSE LOCK	1	NOT USED WITH POWER TRIM
31	18	25191	COTTER PIN, CLEVIS PIN	1	NOT USED WITH POWER TRIM
32	24	99626	SPRING, REVERSE LOCK	1	NOT USED WITH POWER TRIM
33	18	47959	COTTER PIN, SPRING	1	NOT USED WITH POWER TRIM
34		99606	SHAFT, REVERSE LOCK	1	NOT USED WITH POWER TRIM
35	18	45882	COTTER PIN, SHAFT	1	NOT USED WITH POWER TRIM
36		99653	BRACKET, SHOCK ABSORBER	1	NOT USED WITH POWER TRIM
37		99619	SHAFT, SHOCK ABSORBER (LOW	1	NOT USED WITH POWER TRIM
38	17	13794	GROOVE PIN, SHOCK ABSORBER	2	NOT USED WITH POWER TRIM
39	10	40002 77	SCREW, BRACKET	6	NOT USED WITH POWER TRIM