



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	53	26406	RING, SNAP - BALL BEARING RE	1		
2	30	26379	BEARING, BALL - DRIVE SHAFT	1		
3	45	30573	DRIVE SHAFT, DISTRIBUTOR	1		
4		30583A 1	PILOT ASSEMBLY, DISTRIBUTOR	1		
5	30	20066	BEARING, BALL - DISTRIBUTOR	1		
6	24	29275	SPRING, HORSESHOE	1		
7	17	27962	PIN, SPRING TERMINAL	1		
8		32197	STOP, SPRING TERMINAL PIN	1		
9		30580A 1	ECONOMIZER COLLAR AND PIN	1		
10	17	27961	PIN, SPRIGN RETAINER	1		
11	22	25094	FITTING, GREASE - ECONOMIZ	1		
12		32044A 1	THROTTLE ACTUATOR ASSEMB	1		
13	23	26602	BUSHING, NYLON - THROTTLE	1		
14	10	20100	SCREW, THROTTLE ACTUATOR	2		
15	13	26996	LOCKWASHER, THROTTLE ACTI	2		
16	12	20128	WASHER, THROTTLE ACTUATO	2		
17		30645	ADAPTOR, DISTRIBUTOR	1		
18	22	25094	FITTING, GREASE - ADAPTOR	1		
19	10	22040	SCREW< ADAPTOR AND PILOT	3		
20	12	20084	WASHER, ADAPTOR AND PILOT	3		
21	11	20083	NUT, ADAPTOR AND PILOT FAS	3		
22	12	27939	WASHER, THRUST - DISTRIBUT	1		
23	14	27960	TAB WASHER, CAP LOCKING	1		
24	13	27959	WASHER, WAVE - TAB WASHER	1		
25		27955	CAP, ADAPTOR AND PILOT FAST	1		
26	10	20542	SCREW, ADAPTOR AND PILOT T	4		
27	13	26992	LOCKWASHER, ADAPTOR AND F	4		
28	23	29909	SPACER, DRIVEN PULLEY	1		
29		29906A 1	DRIVEN PULLEY ASSEMBLY	1		
30	17	29908	PIN, DRIVEN PULLEY	1		
31		29907	FLANGE, DRIVEN PULLEY	1		
32	28	29910	KEY, MAGNETO DRIVING	1		
33	10	29911	SCREW, PULLEY CLAMPING	1		
34	13	26996	LOCKWASHER, PULLEY CLAMP	1		
35		20140	BELT, TIMING	1		
36		30109	GROUND STRAP ASSEMBLY, AD	1		