



Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1623	2460A11	GEAR HOUSING ASSEMBLY, COM	1	
1	1623	2460A 4	GEAR HOUSING ASSEMBLY	1	
2	16	30661	STUD, GEAR HOUSING TO D	1	
3	16	29078	STUD, GEAR HOUSING TO D	2	
4	16	29975	STUD, WATER PUMP BASE A	1	
5	16	37435	STUD, WATER PUMP BASE A	2	
6	31	32898	BEARING, ROLLER -DRIVE SH	1	
7	45	38459	DRIVE SHAFT (STANDARD)	1	
8	43	31419	GEAR, PINION - DRIVE SHAFT	1	
9	11	30932	NUT, PINION GEAR TO DRIVE :	1	
10	15	30278A 1	SHIM, DRIVE SHAFT BALL BEA	AR	
11	30	20464	BEARING, BALL - DRIVE SHAFT	1	
12	53	30726	RING, RETAINING - BALL BEAR	1	
10	15	30278A 1	SHIM, WATER PUMP BASE TOI	AR	
13	27	32438	GASKET, WATER PUMP BASE	1	
14	25	30224	"O" RING, WATER PUMP BASE	1	
15	46	35976A 1	WATER PUMP BASE ASSEMBL	1	SERIAL 00000000-01852148
15	46	38931A 1	WATER PUMP BASE ASSEMBL	1	SERIAL 01852149-09999999
16	26	31489	OIL SEAL, WATER PUMP BAS	1	
17	26	31507	OIL SEAL, WATER PUMP BAS	1	
18	17	35973	SDOWEL PIN, WATER PUMP	2	
19	27	32433	GASKET, LOWER - WATER PUI	1	
20		32435	PLATE, FACE - WATER PUMP E	1	
21	27	32434	GASKET, UPPER - FACE PLATE	1	
22	46	37433A 1	WATER PUMP BODY ASSEMBL	1	
23		30915	INSERT, WATER PUMP BOD	1	
24	26	31507	OIL SEAL, WATER PUMP BOI	1	
25	12	36446	WASHER, NYLON - WATER IN	1	
26	26	36557	SEAL, RUBBER - WATER INLI	1	
27	47	30221	IMPELLER, WATER PUMP	1	
28	17	29967	PIN, IMPELLER DRIVE	1	
29	10	30720	SCREW, WATER PUMP BODY TC	1	
30	13	26992	LOCKWASHER, WATER PUMP	3	
31	11	29598	NUT, WATER PUMP BODY FAS	2	
32	13	26993	LOCKWASHER, WATER PUMP	1	
33	11	28770	NUT, WATER PUMP BODY FAS	1	
34	25	30271	RING, RUBBER - CENTRIFUGAI	1	
35	23	29804	SLEEVE, GUIDE - WATER INLE	1	
36	25	30613	"O" RING, UPPER - DRIVE SHA	1	
37		37641	SEAL, EXHAUST TUBE	1	
38		28051	PLATE, SUPPORT - EXHAUST	1	