



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		30263A 2	FUEL PUMP ASSEMBLY - UPPER	1,1,1		
2	21	30430A 1	CHECK VALVE ASSEMBLY	1,1,1		
3		23014A 1	DIAPHRAGM KIT	1,1,1		2,4
4			GASKET, CHECK VALVE TO	2,2,2		2,4
5			GASKET, FUEL PUMP	2,2,2		2,4
6			GASKET, FUEL PUMP COVE	1,1,1		2,4
7		23004	RETAINER, CHECK VALVE	1,1,1		
8	10	20037	SCREW, RETAINER TO HOUSII	2,2,2		
9		30461A 2	FUEL PUMP ASSEMBLY - LOWEF	1,1,1		
2	21	30430A 1	CHECK VALVE ASSEMBLY	1,1,1		
3		23014A 1	DIAPHRAGM KIT	1,1,1		2,4
4			GASKET, CHECK VALVE TO	2,2,2		2,4
5			GASKET, FUEL PUMP	2,2,2		2,4
6			GASKET, FUEL PUMP COVE	1,1,1		2,4
7		23004	RETAINER, CHECK VALVE	1,1,1		
8	10	20037	SCREW, RETAINER TO HOUSII	2,2,2		
10		30275	COVER, FUEL PUMP	2,2,2		
11	10	29878	SCREW, PUMP MOUNTING (1-1/	1,1,1		
12	10	30274	SCREW, PUMP MOUNTING (1-3/	2,2,2		
13	10	38036	SCREW, PUMP MOUNTING (1-1/	1,1,1		
14	10	30273	SCREW, PUMP MOUNTING (1-7/	2,2,2		
15	32	32256A 1	FUEL LINE ASSY, PUMP TO CAR	1,1,1		
16	22	30174	ELBOW, UPPER CARBURETOR E	1,1,1		
17	22	30175	SLEEVE, CARBURETOR STRAINI	1,1,1		
18	22	30177	NUT, UPPER CARBURETOR STF	1,1,1		
19	32	31552A 1	FUEL LINE ASSY, PUMP TO PUM	1,1,1		
20	32	31553A 1	FUEL LINE ASSY, PUMP TO CAR	1,1,1		
21	32	30176	FUEL LINE, ADAPTOR TO LOWE	1,1,1		
22	22	30174	ELBOW, LOWER FUEL PUMP INL	1,1,1		
23	22	30175	SLEEVE, FUEL PUMP INLET ELB	1,1,1		
24	22	30177	NUT, FUEL PUMP INLET ELBOW	1,1,1		
25	22	37682	ELBOW, FUEL LINE TO ADAPTO	1,1,1		
26		30186	ADAPTOR, CHECK UNIT (FUEL LI	1,1,1		
27		30187	STEM, CHECK UNIT ADAPTOR	1,1,1		
28	25	20415	"O" RING, ADAPTOR STEM	1,1,1		
29	24	30189	SPRING, ADAPTOR STEM	1,1,1		
30		30188	CUP WASHER, ADAPTOR	1,1,1		
31	10	37561	SCREW, ADAPTOR TO BOTTOM	2,2,2		
32	11	20184	NUT, ADAPTOR FASTENING SCF	2,2,2		
33	32	31550A 1	FUEL LINE ASSEMBLY, CARBURI	2,2,2		