



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	53	26406	RING, SNAP - BALL BEARING RE	1,1,1		
2	30	26379	BEARING, BALL - DRIVE SHAFT	1,1,1		
3	45	30573	DRIVE SHAFT, DISTRIBUTOR	1,1,1		
4		39559A 1	PILOT ASSEMBLY, DISTRIBUTOR	1,1	SERIAL 00000000-02099925	
4		45483A 4	PILOT ASSEMBLY, DISTRIBUTOR	,1	SERIAL 02099926-09999999	
5	12	45484	WASHER, DISTRIBUTOR TO AD	,1,1		
4		45960A 1	PILOT ASSEMBLY, DISTRIBUTOR	,1		
6	30	20066	BEARING, BALL - DISTRIBUTOR	1,1,1		
7	24	29275	SPRING, HORSESHOE	1,1,1		
8	17	27962	PIN, SPRING TERMINAL	1,1,1		
9		32197	STOP, SPRING TERMINAL	1,1,1		
10		30580A 1	ECONOMIZER COLLAR AND PIN	1,1,1		
11	17	27961	PIN, SPRING RETAINER	1,1,1		
12	22	25094	FITTING, GREASE - ECONOMIZ	1,1,1		
13		32044A 1	THROTTLE ACTUATOR ASSEMB	1,1,1		
14	23	26602	BUSHING, NYLON - THROTTLE	1,1,1		
15	10	20100	SCREW, THROTTLE ACTUATOR	2,2,2		
16	13	26996	LOCKWASHER, THROTTLE ACTI	2,2,2		
17	12	20128	WASHER, THROTTLE ACTUATO	2,2,2		
18		30645	ADAPTOR, DISTRIBUTOR	1,1,1		
19	22	25094	FITTING, GREASE - ADAPTOR	1,1,1		
20		30585	BRACKET, STOP	1,1,1		
21	10	28636	SCREW, STOP BRACKET TO DIS	2,2,2		
22	12	20533	WASHER, STOP BRACKET FAST	2,2,2		
23		37747	GROUND STRAP, STOP BRACK	1,		
24	10	24228	SCREW, STOP BRACKET ADJUS	3,3,3		
25	11	20890	NUT, STOP BRACKET ADJUSTIN	3,3,3		
26		26852	CAP, NYLON - ADJUSTING SCRE	3,3,3		
27	10	22040	SCREW, ADAPTOR AND PILOT T	3,3,3		
28	12	20084	WASHER, ADAPTOR AND PILOT	3,3,3		
29	11	20083	NUT, ADAPTOR AND PILOT FAS	3,3,3		
30	12	27939	WASHER, THRUST - DISTRIBUT	1,1,1		
31	14	27960	TAB WASHER, CAP LOCKING	1,1,1		
32	13	27959	WASHER, WAVE - TAB WASHER	1,1,1		
33		27955	CAP, ADAPTOR AND PILOT FAST	1,1,1		
34	10	31299	SCREW, ADAPTOR AND PILOT T	4,4		
34	10	20532	SCREW, ADAPTOR AND PILOT T	,4		
35	13	26992	LOCKWASHER, ADAPTOR AND F	,4		
36	23	29909	SPACER, DRIVEN PULLEY	1,1,1		
37		29906A 1	DRIVEN PULLEY ASSEMBLY	1,1,1		
38	17	28909	PIN, DRIVEN PULLEY	1,1,1		