



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		850675	ELECTRICAL MOUNTING PLATE	1		
2	339	850227	IGNITION COIL	6		
3	84	821945A63	HI-TENSION CABLE	1		
4	85	63709A 1	BOOT	1		
5	33	855672	SPARK PLUG	6	(PLATINUM)	
5	33	855717	SPARK PLUG	OPT	(NON-PLATINUM)	7
6		850676 1	SPACER	6		
7	10	850898	SCREW (1/4-20 X 3-1/4 IN.)	6		
8		825762	MAP SENSOR	1		
9	10	821291 14	SCREW (M6 X 14)	2		
10	32	99126 88	TUBING (.31 IN.)	1		
11	10	60411	SCREW (.312-18 X 1-1/4 IN.)	4		
12	12	49436	WASHER	4		
13	25	833155	GROMMET	4		
14	23	850234 1	BUSHING	4		
15	10	821291 14	SCREW-ENGINE HARNESS GRO	2		
16	12	35044	WASHER	6		
17	11	56374	NUT	6		
18	84	819514A14	TRIM HARNESS	1		
19		828151A 1	RELAY	3		
20		NSS	DECAL-TRIM RELAY	3		3
21		828102	BRACKET	3		
22	23	818968	BUSHING	3		
23	25	818967	GROMMET	3		
24	10	821291 25	SCREW (M6 X 25)	2		
24	10	821291 35	SCREW (M6 X 35)	1		
25	23	91912	BUSHING	1		
26	54	816311	STA STRAP	2		
27	84	850681A 2	ENGINE HARNESS	1		
28	84	856624A 2	HARNESS-ALTERNATOR (SER)	1		
29	88	812619	FUSE	4		
30		NSS	BRACKET-FUSE HOLDER	1		3
31	10	855634	SCREW (M4 X 8)	2		
32		856496A 8	ECU	1	(135)	
32		856496A 9	ECU	1	(150)	
33		830897	PAD	1		
34	10	821300 25	SCREW (M6 X 25)	3		
35	23	831870 1	BUSHING	6		
36	25	834985	GROMMET	3		
37	10	821291 14	SCREW (M6 X 14)	2		
38	54	952947	CLIP	1		