



AIR HANDLER COMPONENTS

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		855633T16	AIR HANDLER	1		
1		855420A	1	ADAPTOR PLATE KIT	1	
2	27	14697	3	GASKET	1	5
3	27	850058	1	GASKET	1	5
4		855952T	3	REED BLOCK	6	
5	10	55715		SCREW (1/4-20 X .88)	12	
6		857149T	2	OIL PUMP	1	
7	23	855364		BUSHING	6	
8	25	855362		GROMMET	6	
9	10	818934	35	SCREW (M8 X 35)	3	
10	12	817274		WASHER	6	
11		850248A	2	AIR PLENUM KIT	1	
12	10	818934	30	SCREW	3	
13		858535		TEMPERATURE SENSOR	1	
14	25	62702	1	O RING	1	
15	10	40019	87	SCREW (M4 X 16)	2	
16		855422A	1	THROTTLE BODY KIT	1	
17	25	855423		O RING	1	
18	10	821300	40	SCREW	4	
19	10	19937	16	SCREW (M6 x 16)	3	
20		854445		MAP SENSOR	1	
21		804873		BRACKET	1	
-		879808T01		POWERHEAD	1	(135/150)
-		879809T01		POWERHEAD	1	(175)