



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		858221T 4	FUEL RAIL	1	(PORT)(w/O FUEL INJECTORS)	
2		858222A 3	FUEL RAIL	1	(STARBOARD)(w/O FUEL INJECTORS)	
3	54	804830	CLAMP	4		
4	54	804831	CLAMP	4		
5	54	880816	CLAMP	1		
6	54	804832	CLAMP	2		
7	19	804834	FUEL PLUG	1		
8	19	804835	AIR PLUG	1		
9		804837	AIR VALVE KIT	1		
10		804838A 1	FUEL VALVE KIT	1		
11	19	804839	CAP	2		
12	25	880809	O RING KIT	1		
13	25	804840	O RING KIT	1		
14	25	804530	O RING KIT	1		
15		804533	DIAPHRAGM	1		
16	24	804534	SPRING	1		
17	25	804536	O RING	1		
18		804535	COVER	1		
19		804526	SCREW (M5 X 16)	4		
20		804532	O RING (16 per Kit)	1		
21		804525	SCREW (M5 X 8)	15		
22	25	804529	O RING KIT	1		
23		880807T	AIR REGULATOR	1	(PORT)	
24	54	880808	CLAMP	1		
25		804841	FUEL INJECTOR	6		
26		850065A 11	DIRECT INJECTOR	6	(S/N-0T598999 & BELOW)	
26		883078A 3	DIRECT INJECTOR	6	(SALTWATER)(S/N-0T598999 & I	
26		883078A 4	DIRECT INJECTOR	6	(ALL)(S/N-0T599000 & UP)	
27	26	804875	SEAL KIT-Direct Injector	6		
28	16	858778	STUD	4		
29	11	826292	NUT	4		
30	12	828694A 1	WASHER - CUPPED	6		5
31	54	859376	CLIP	4		
-		879808T01	POWERHEAD	1	(135/150)	
-		879809T01	POWERHEAD	1	(175)	