



19565

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		43429	IGNITION PLATE	1		
2	332	7778A	SWITCH BOX	2		
3	10	13669	SCREW, (12-24 x 2.00), SWITCH	2		
4	23	94453	BUSHING, SWITCH BOX SCREW	2		
5	84	62310A	CABLE ASSEMBLY, SWITCH BOX	1		
6	11	45076	NUT, (#10-32), SWITCH BOX TER	20		
7	84	60871A10	WIRE ASSEMBLY, SWITCH BOX	2		
8	10	62568	SCREW, (#10-16 x .375), WIRE A	3		
9	84	65999A	CABLE ASSEMBLY, (Black)	1		
10	10	69092	SCREW, (1.25), IGNITION PLATE	3		
11	13	26393	LOCKWASHER, (.312), IGNITION	3		
12	12	36042	WASHER, IGNITION PLATE SCRI	6		
13	12	67264	WASHER, (Rubber), IGNITION PL	6		
14	23	67268	BUSHING, IGNITION PLATE SCRI	3		
15	87	33386A	SWITCH ASSEMBLY	1		
16	10	38055	SCREW, (.190-32 X .62), MERCUF	1		
17	11	45076	NUT, (#10-32), MERCURY SWITC	1		
18	10	87926	SCREW, (#10-32 x .500), LEAD AT	1		
19	84	88439A	BATTERY CABLE, Positive	1		
19	84	88439A	BATTERY CABLE, Negative	1		
20	84	96220A12	HARNESS, ENGINE (USE W/O RI	1		
20	84	96220A	HARNESS, ENGINE (USE W/REC	1		
21	88	79091	FUSE, (20 Ampere)	1		
22	84	95084A	CABLE ASSEMBLY, FUSE	1		
23	54	47483	J CLIP	3		
24	54	816311	CABLE TIE, (8.00 Inches), HARNE	AF		
25	89	68258A	STARTER SOLENOID	1		
26	11	45076	NUT, (#10-32), SOLENOID TERMI	2		
27	13	53166	LOCKWASHER, (.312), SOLENOID	2		
28	11	68292	NUT, (.312-18), SOLENOID TERM	2		
29	10	31716	SCREW, (.250-20 x .62), SOLENOI	2		
30	13	26392	LOCKWASHER, (.250)	2		
31	84	65999A	CABLE ASSEMBLY, (Black), UPPE	1		
32	84	91865A	CABLE ASSEMBLY (3" - WHITE/B	1		
32	84	88528A	CABLE ASSEMBLY (6" - RED/WH	1		
33	86	19437	TERMINAL BLOCK	1		
34	10	38055	SCREW, (.190-32 X .62)	2		
35	12	89302	WASHER, (.203 x .406 x .040)	2		
36	11	45076	NUT, (#10-32)	2		
37		814422T	COVER, IGNITION PLATE	1		
38	10	88447	SCREW, (.190-32 x .1.62)	2		