



18523

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	3401	8718A 1	TRANSOM BRACKET (STARBOARD)	1	
1	3401	8718A 2	TRANSOM BRACKET (STARBOARD)	1	
2	3400	8716A 5	TRANSOM BRACKET (PORT) (BLACK)	1	
2	3400	8716A 6	TRANSOM BRACKET (PORT) (GRAY)	1	
3	22	98727	FITTING, Grease, PORT TRANS	1	
5		99170A 1	TILT TUBE	1	
6	11	90068T	NUT, TILT TUBE (1"-14) (BLACK)	1	
6	11	90068T 6	NUT, TILT TUBE (1"-14) (GRAY)	1	
7	25	45711	O-RING, TILT TUBE	1	1
8	13	88750	WAVE WASHER, TILT TUBE	2	
9	11	56041	NUT, (.875-14), TILT TUBE	1	
10	10	67755 1	SCREW, (.500-20 x 4.500), TRANS	4	
11	12	28421	WASHER, TRANSOM BRACKET BOLT	4	
11	12	24501	WASHER, TRANSOM BRACKET BOLT	2	(UPPER-SEA RAY)
12	11	91962	NUT, TRANSOM BRACKET BOLT	4	
13		99629A 2	LEVER ASSEMBLY, TILT LOCK	1	
14	13	99611	WAVE WASHER, TILT LEVER	1	
15	23	65830	NYLINER, TILT LEVER	2	
16		99633	KNOB, TILT LOCK LEVER (BLACK)	1	
16		99633T 6	KNOB, TILT LOCK LEVER (GRAY)	1	
17	17	99615	PIN, Groove	1	
18	24	99622	SPRING	1	
19	17	99604	PIN, Groove	1	
20	10	96930A 1	BOLT ASSEMBLY, TILT LOCK	1	
21	11	23161	NUT, (.375-24), BOLT	1	