



18956

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1647	9148A18	GEAR HOUSING (LONG) (BLACK)	1	(Standard)	
-	1647	9148A19	GEAR HOUSING (X-LONG) (BLAC)	1	(Standard)	
-	1647	9148A20	GEAR HOUSING (LONG) (GRAY)	1	(Standard)	
-	1647	9148A21	GEAR HOUSING (X-LONG) (GRAY)	1	(Standard)	
-	1647	9148A23	GEAR HOUSING (LONG)	1	(Standard)(MARINER 135)	
-	1647	9148A38	GEAR HOUSING (X-LONG)	1	(Standard)(MARINER 135)	
-	1647	9148A27	GEAR HOUSING (X-LONG) (BLAC)	1	(Counter Rotation)	
-	1647	9148A28	GEAR HOUSING (X-LONG) (GRAY)	1	(Counter Rotation)	
1	1647	9148A11	GEAR HOUSING ASSEMBLY (BI	1		
1	1647	9148A12	GEAR HOUSING ASSEMBLY (G	1		
2	22	85822A	CONNECTOR ASSEMBLY, SP	1		
3	17	20033	PIN, Dowel, GEAR HOUSING	2		
4	16	78638	STUD, (.438 x 3.12), GEAR HO	1		
4	16	18978	STUD, (.438 x 3.69), GEAR HO	1		
5	16	57920	STUD, (.44 x 2.06), GEAR HOL	2		
6	16	56297	STUD, (.312 x 3.38), WATER F	1		
7	16	30667	STUD, (.250-20/ 250-28 x 3.12	2		
8	31	42647A	BEARING ASSEMBLY, Roller, I	1		
9	23	43998	SLEEVE, LUBRICATION	1		
11	45	44000	DRIVESHAFT (LONG)	1		
11	45	44209	DRIVESHAFT (X-LONG)	1		
12		N.S.S.	Not Sold Seperate, Pinion Gear (F	1		
13	12	92721	WASHER, PINION GEAR	1		
14	11	35921	NUT, (.625-18), PINION GEAR T	1		
15	15	42637A	SHIM SET	AR		
16	31	36387A	BEARING, Roller, DRIVE SHAFT	1		
17	11	42633	NUT, DRIVE SHAFT BEARING	1		
18	46	42579A	WATER PUMP BASE ASSEMBL	1		8
19	27	42631	GASKET, WATER PUMP TO C	1		1,8,7
20	25	90011	O-RING, (2.175 x .175), WATE	1		1,8,7
20	25	38099	O-RING, WATER PUMP (2.10	1		1,8,7
21	26	89238	OIL SEAL, WATER PUMP	1		8,7
22	26	16977	OIL SEAL, WATER PUMP	1		8,7
23	27	85608	GASKET, LOWER - WATER P	1		1,8,7
24	27	85609	GASKET, UPPER - WATER PL	1		1,8,7
25		32435	FACE PLATE, WATER PUMP	1		8
25		45048	FACE PLATE, WATER PUMP	1	(MARINER 135)	
26	46	96148A	WATER PUMP BODY ASSEMBL	1		8
26	46	96148A	WATER PUMP ASSEMBLY	1	(MARINER 135)	
27		48752	INSERT, WATER PUMP BOD	1		8
27		52169	INSERT, WATER PUMP	1	(MARINER 135)	