

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		79918A 1	COVER KIT, FLYWHEEL	1		
2		79022	MARKER, TIMING	1		
3	10	37572	SCREW, (.190-32 x .380), TIMING	2		
4	12	72761	WASHER, TIMING MARKER SC	2		
5	19	89219	PLUG, FLYWHEEL COVER	1		
6	19	45907	PLUG, (Yellow), FLYWHEEL	1		
7	11	52901	NUT, (.625-18), FLYWHEEL	1		
8	12	68229	WASHER, FLYWHEEL	1		
9	257	7555A 8	FLYWHEEL	1	(Use with Stator Lamination Thickr	
9	257	7555A17	FLYWHEEL	1	(Use with Stator Lamination Thickr	
10	10	32417	SCREW, (.250-28 x .625), FLYWI	8		
11	10	68997	SCREW, (.312-24 x .750), FLYWI	8		
12	398	5454A32	STATOR (USE WITH VOLTAGE R	1	(Lamination Thickness is 1/2 In.)	
12	398	5454A35	STATOR (USE WITH VOLTAGE R	1	(Lamination Thickness is 5/8 In.)	
13	10	76566	SCREW, (#10-24 x 1.00), STATOR	4		
15		96455A 9	TRIGGER PLATE ASSEMBLY	1		
17	50	79472	STARTER MOTOR (8 TOOTH PIN)	1		
18		56703	COLLAR, STARTER MOTOR	2		
19		68042	STOP, RUBBER - STARTER MOT	2		
20	13	26992	LOCKWASHER, (.250), STARTER	1		
21	11	20890	NUT, (.250-20), STARTER MOTOF	1		
22	84	93388A 2	WIRE, (Black), SOLENOID TO ST	1		
23	10	69035	SCREW AND LOCKWASHER, (.2	1		
24	84	93388A 1	CABLE ASSEMBLY, Black, PLATE	1		
25	339	7370A13	IGNITION COIL ASSEMBLY, IGNI	6		
26		67614	COVER, IGNITION COIL	3		
27	10	88447	SCREW, (.190-32 x 1.62), IGNITIO	12		
28	11	45076	NUT, (#10-32), IGNITION COIL TE	12		
29	84	88807A 6	WIRE, (3.50 Inches) Black, IGNITII	6		
30	10	68513	SCREW, (#10-32 x .375), GROUN	6		
31	84	99215A25	LEAD ASSEMBLY, HIGH TENSIO	6		
32	85	63709A 1	BOOT/TERMINAL KIT, HIGH TE	6		
33	33	13686 2	SPARK PLUG	6		
34	84	69738A 1	HARNESS, COIL TO SWITCH BO	1		
34	84	69739A 2	HARNESS, COIL TO SWITCH BO	1		
35	12	30164	WASHER, (.192 x .375 x .0312), IG	12		

