



19040

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1499	8710A 4	SWIVEL BRACKET ASSEMBLY (B)	1	
1	1499	8710A13	SWIVEL BRACKET ASSEMBLY (G)	1	
1	1499	8710A15	SWIVEL BRACKET ASSEMBLY (O)	1	
2	26	87735	SEAL, Oil, SWIVEL BRACKET (L)	1	
3	23	67669	BUSHING, SWIVEL BRACKET -	2	
4	25	33466	O-RING, SWIVEL BRACKET - (U)	1	2
5	23	67668	SPACER, SWIVEL BRACKET - (L)	1	
6	22	74036	FITTING, Grease	2	
7	23	99608	BUSHING, SWIVEL BRACKET	2	
8	17	67706A18	SWIVEL PIN AND STEERING ARM	1	
8	17	67706A17	SWIVEL PIN AND STEERING ARM	1	
8	17	67706A19	SWIVEL PIN AND STEERING ARM	1	
9	10	78689	SCREW, (.437-20 x 7.50), STEERING	2	
10		78687	MOUNT, RUBBER - (UPPER)	2	
11	12	66921	WASHER, UPPER MOUNT BOLT	2	
12	12	78688	WASHER, UPPER MOUNT BOLT	2	
13	11	34933	NUT, (.437-20), UPPER MOUNT B	2	
14		92876A 1	LINK ASSEMBLY, Steering (BLACK)	1	
15	10	14000	SCREW, (.375-24 x 1.25), STEERING	1	
16	11	34863	NUT, (.375-24), STEERING LINK	2	
17	12	34931	WASHER, (.406 x .734 x .063) Stai	2	
18	13	78854	WAVE WASHER, BOTTOM YOKE	1	
19		86580A 1	BOTTOM YOKE (BLACK)	1	
19		86580A 2	BOTTOM YOKE (GRAY)	1	
19		86580A 3	BOTTOM YOKE (OYSTER)	1	
20	53	67684	RING, Retaining, BOTTOM YOKE	1	
21	12	67670	WASHER, THRUST - SWIVEL BR	1	
22		88882	BUMPER, Top Yoke, TOP YOKE	1	
23		95164A 9	TRIM SENDER ASSEMBLY	1	
24	10	56682	SCREW, (#10-24 x .750), TRIM SE	2	
25	13	26396	LOCKWASHER, (#10), TRIM, SEN	2	
26	12	89302	WASHER, (.203 x .406 x .040), TR	2	
27	10	64014	SCREW, (.250-28 x .500), SWIVEL	1	
28	54	54457	J CLIP	1	
-	27	90484A88	GASKET SET		