



1395

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1590	8343T10	DRIVESHAFT HOUSING	1	(BLACK-LONG)	
1	3503	813563T 1	DRIVESHAFT HOUSING	1	(BLACK-X-LONG)	
1	1590	8343A13	DRIVESHAFT HOUSING	1	(BLACK-JET)	
2	16	56295	STUD, (.437 x 2.69)	2		
3	10	63474	SCREW, (.500-20 x 6.00)	2		
4		88238A10	GROUND WIRE ASSEMBLY	2		
5		78249	MOUNT, Lower	2	(135)(JET)	
5		77327	MOUNT, Lower	2	(ALL OTHER MODELS)	
6	12	49339	WASHER, (.8125)	2		
7	11	826708 17	NUT, (.500-20)	2		
8	10	41508	SCREW, (.250-20 x .500)	1		
9	12	45176	WASHER, (.453 x .812 x .105)	2		
10	11	34933	NUT, (.437-20)	2		
11	54	67076	CLAMP	2		
12	10	66727	SCREW, (.312-18 x 1.250)	4		
13		67077T	COVER	2		
14	10	88417	SCREW, (#12-24 x .620)	4		
15	11	35521	NUT	4		
16	12	48926	WASHER	1		
17	11	34933	NUT, (.437-20)	1		
18	12	20553	WASHER, (.406 x .734 x .063)	4		
19	11	69254	NUT	4		
20		828212	IDLE EXHAUST BOOT	1		
21	19	64649	PLUG	1		
22	27	99173 4	GASKET	1		2
23		66350	SEAL (LOWER)	1	SN# 0T800999 & Below	
23		66350001	SEAL (Lower)	1	SN# 0T801000 & Up	
24		18276	EXHAUST TUBE	1		
25		17726 1	SEAL (UPPER)	1		
26		812834A 2	EXHAUST EXTENSION	1	(135/140/150/XR6/MAGNUM III)	
27	16	883085	STUD	4		
28	12	35044	WASHER, (.281 x .625 x .065 - S	4		
29	11	888500	NUT	4		
30		41942 4	EXHAUST EXTENSION	1	(200)(JET)	
31	32	859097 1	WATER TUBE	1	(LONG)(JET)	
31	32	859097 2	WATER TUBE	1	(X-LONG)	
32		18233A 8	DRIVESHAFT HOUSING PLATE	1	(WITHOUT TWO HOLES IN THE	
32		18233A20	DRIVESHAFT HOUSING PLATE	1	(WITH TWO HOLES IN THE	
33		814701 2	SEAL	1		
34		68011	BRACKET	1		
35	10	678508	SCREW, (#10-16 x .500)	12		