



54 Mineral Oil (Purchase Locally)

A = TO TELL TALE B = TO STARBOARD FUEL RAIL C = TO FUEL COOLER
 D = TO TOP OF AIR HANDLER E = QTY. OF ONE (1) ON EACH SIDE OF COMPRESSOR FLANGE
 G = TO VAPOR SEPARATOR

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		831998A 9	AIR COMPRESSOR (SEE BREAK)	1		
2	10	855939 12	SCREW (M6 X 12)	5		
3		832823 1	PULLEY	1		
4	10	40108 25	SCREW	2		
5	32	850251 1	HOSE	1		
6	23	856523 29	INSULATOR SLEEVE (15 IN.)	1		
7		852379T 5	FUEL RAIL	1	(STARBOARD)	
8		850065 3	INJECTOR	6		
9	54	855697	CLAMP (16.2)	4		
10	32	855643 61	HOSE (16 IN.)	2		
11	16	92345	STUD	1		
12	12	854640	WASHER	2		
13	11	35814	NUT	1		
14	54	816311	STA STRAP	8		
15		852378T 5	FUEL RAIL	1	(PORT)	
16	32	830756109	TUBING (22-1/2 IN.)	1		
17	21	826810	CHECK VALVE	1		
18	32	830757 80	TUBING (2-1/2 IN.)	1		
19	32	834764 63	TUBING (28-1/2 IN.)	1		
20	54	856880	CLAMP (15.3)	2		
21	32	856060 64	TUBING-AIR COMPRESSOR OIL (1		
22	10	821045 10	SCREW (M5 X 10)	4		
23	54	46997	CLAMP	4		
24	16	852961	STUD	4		
25	11	826292	NUT	4		
26		NSS	HOSE (30 IN.)	1	(DESIGN I - 3/8 IN. I.D. - REFER 3	
26	32	856822A 3	HOSE (30 IN.)	1	(DESIGN II - 5/16 IN. I.D. - W/IN	
27	32	855848 1	HOSE	1		
28	12	828694A 1	CUPPED WASHER	6		
29	54	856880	CLAMP (15.3)	4		
30	23	856869 53	INSULATOR SLEEVE (18 IN.)	1		
31	54	816311	STA-STRAP	1		