



1350

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
0	1647	9148786	GEAR HOUSING-COMLETE	1	[X-LONG - 1.87:1]	
0	1647	9148783	GEAR HOUSING-COMLETE	1	[X-LONG - 2:1]	
1	1647	9148793	GEAR HOUSING, (Basic)	1		
2		89594A 1	FOLLOWER	1		
3		78956 2	SHIFT CAM	1		
4		828287	ROD	1		
5	15	44491A 1	SHIM SET	AR		
6		828830A 2	BEARING ADAPTOR ASSEMBL	1		
7	31	814653	BEARING ASSEMBLY-ROLLEF	1		
8	12	815481	WASHER-THRUST	1		
9	31	815480	THRUST BEARING	1		
10	43	828702A 2	THRUST GEAR, (15/28)	1	(1.87:1 Gear Ratio-150)	
10	43	828704A 2	REVERSE GEAR, (14/28)	1	(2:1 Gear Ratio-135)	
11	31	15844	BEARING ASSEMBLY-ROLLEF	1		
12	24	30893	SPRING	1		
13	52	854735T	SLIDING CLUTCH	1		
14	17	30632	CROSS PIN	1		
15	17	828356	DETENT PIN	1		
16	44	828951	PROPELLER SHAFT	1		
17	43	828701A 1	FORWARD GEAR, (15/28)	1	(1.87:1 Gear Ratio-150)	
17	43	828703A 1	FORWARD GEAR, (14/28)	1	(2:1 Gear Ratio-135)	
18	23	17615 14	SPACER SHIM, (.206)	AR		
18	23	17615 15	SPACER SHIM, (.208)	AR		
18	23	17615 16	SPACER SHIM, (.210)	AR		
18	23	17615 17	SPACER SHIM, (.212)	AR		
18	23	17615 18	SPACER SHIM, (.214)	AR		
18	23	17615 19	SPACER SHIM, (.216)	AR		
18	23	17615 20	SPACER SHIM, (.218)	AR		
18	23	17615 21	SPACER SHIM, (.220)	AR		
18	23	17615 22	SPACER SHIM, (.222)	AR		
18	23	17615 23	SPACER SHIM, (.224)	AR		
18	23	17615 24	SPACER SHIM, (.226)	AR		
18	23	17615 25	SPACER SHIM, (.228)	AR		
18	23	17615 26	SPACER SHIM, (.230)	AR		
19	31	815480	THRUST BEARING	1		
20	12	815481	WASHER-THRUST	1		
21		828831A 3	BEARING ADAPTOR ASSEMBL	1		
22	31	814653	BEARING ASSEMBLY-ROLLEF	1		
23	12	18448	WASHER-THRUST	2		
24	31	15842	BEARING-THRUST	2		
25		818281 1	FACE THRUST	2		