



AIR HANDLER COMPONENTS

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		855633T16	AIR HANDLER	1		
1		855420A	1 ADAPTOR PLATE KIT	1		
2	27	14697	3 GASKET	1		5
3	27	850058	1 GASKET	1		5
4		855952T	3 REED BLOCK	6		
5	10	55715	SCREW (1/4-20 X .88)	12		
6		857149T	2 OIL PUMP	1		
7	23	855364	BUSHING	6		
8	25	855362	GROMMET	6		
9	10	818934	35 SCREW (M8 X 35)	3		
10	12	817274	WASHER	6		
11		850248A	2 AIR PLENUM KIT	1		
12	10	818934	30 SCREW	3		
13		858535	TEMPERATURE SENSOR	1		
14	25	62702	1 O RING	1		
15	10	40019	87 SCREW (M4 X 16)	2		
16		855422A	1 THROTTLE BODY KIT	1		
17	25	855423	O RING	1		
18	10	821300	40 SCREW	4		
19	10	19937	16 SCREW (M6 x 16)	3		
20		854445	MAP SENSOR	1		
21		804873	BRACKET	1		
-		879808T01	POWERHEAD	1	(135/150)	
-		879809T01	POWERHEAD	1	(175)	

