



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		827325T11	COVER ASSEMBLY	1		
2	25	821555	GROMMET	2		
3	35	853333T	AIR FILTER	1		
4		853352	COVER	1		
5	25	857101	GROMMET	1		
6	25	855613	GROMMET	1	(150/175)	
7	25	855613	GROMMET	1	(135)	
8		855633T16	AIR HANDLER ASSEMBLY	1	(SEE BREAKDOWN ON AIR HAN	
9	37	881865	DECAL-CAUTION-START IN GE.	1		
10		855756A	BRACKET	1		
11	23	803818	SLEEVE	1		
12	10	19937 16	SCREW (M6 X 16)	4		
13		855843	FUEL PUMP	1		
14	54	13791	CLAMP	4		
15	32	856778	HOSE	1		
16	22	855802A	ELBOW	1		
17	22	856812	FITTING	1		
18	25	805062	O RING	1		
19	25	856928	GROMMET	1		
20		828358	CRANK POSITION SENSOR	1		
21	10	40011107	SCREW	2		
22	54	883080	J CLAMP	2		
23	10	817504	SCREW (1/4-20 X 1-1/2 IN.)	12		
24		821583	PIN	1		5
25	37	804657A01	DECAL EPA LABEL	1	(2001)	22
25	37	804657A02	DECAL-EPA LABEL	1	(150/175)(2002)	22
25	37	883929A02	DECAL-EPA	1	(135)(2002)	22
25	37	804657A03	DECAL-EPA	1	(150/175)(2003)	22,1
25	37	883929A03	DECAL-EPA	1	(135)(2003)	22,1
26		61990	CABLE TIE (14 IN.)	1		
27	84	881831	CABLE	1		
28	10	19937 16	SCREW (M6 X 16)	1		
29	54	63300	CLAMP	1		
30		826115	CLAMP	1		
-		879808T01	POWERHEAD	1	(135/150)	
-		879809T01	POWERHEAD	1	(175)	