



8678

| Parts List |       |           |                              |     |                 |          |
|------------|-------|-----------|------------------------------|-----|-----------------|----------|
| Ref        | Class | Part      | Description                  | Qty | Comment         | Footnote |
| 1          |       | 880194T05 | COVER ASSEMBLY               | 1   |                 |          |
| 2          | 25    | 840525    | GROMMET                      | 2   |                 |          |
| 3          | 25    | 20116     | GROMMET                      | 1   |                 |          |
| 4          | 25    | 855613    | GROMMET                      | 1   | (200)           |          |
| 5          | 25    | 882840    | GROMMET                      | 1   | (150)           |          |
| 6          |       | 828358    | SENSOR                       | 1   |                 |          |
| 7          | 10    | 40011107  | SCREW, (M5 x 16)             | 2   |                 |          |
| 8          |       | 821583    | PIN, Special                 | 1   |                 | 5        |
| 9          |       | 896552T01 | AIR HANDLER ASSEMBLY         | 1   |                 |          |
| 10         | 54    | 883080    | J CLIP                       | 2   |                 |          |
| 11         | 10    | 817504    | SCREW, (.250-20 x 1.500)     | 12  |                 |          |
| 12         | 54    | 55098     | J CLIP                       | 1   |                 |          |
| 13         | 37    | 881865    | DECAL, Caution-Start in Gear | 1   | (Start In Gear) |          |
| -          |       | 883511T04 | POWERHEAD                    | 1   | (150)           |          |
| -          |       | 883600T04 | POWERHEAD                    | 1   | (200)           |          |