



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	27	19050 3	GASKET	1		2,3
2		827323A 2	DIVIDER PLATE	1		3
3	26	814754	SEAL	1		2,3
4	54	814634	J-CLAMP	4		3
5	10	826356	SCREW (5/16-18 X 1-1/2)	20		3
6	22	814430	FITTING	1		3
7	22	92007	FITTING (90 DEGREES)	1		3
8	32	830756109	HOSE (23-1/2 IN.)	1		3
9	54	816311	STA-STRAP	2		3
10		68729	COVER-RELIEF VALVE	1		3
11	10	74824	SCREW (5/16-18 X 1-1/4 IN.)	4		3
12	27	78690	GASKET	2		2,3
13	10	69570	SCREW (10-16 X 3/4 IN.)	1		3
14	12	76451	WASHER	1		3
15		14479	DIAPHRAGM	1		3
16		16496	WATER DEFLECTOR	1		3
17		16497A 1	PLATE	1		3
18	24	64878	SPRING	1		3
19	12	85303	WASHER	1		3
20		14480	POPPET	1		3
21	25	64872	GROMMET	1		3
22		65848	CARRIER	1		3
23	27	99176 3	GASKET	1		2,3
24		18260A 2	EXHAUST PATE	1		
25	22	89772 1	CONNECTOR (STRAIGHT)	1		
26	17	43044	DOWEL PIN	2		
27		814701 1	SEAL	1		
28		68010 1	BRACKET	1		
29	10	812832	SCREW (1/2 IN.)	8		
30	12	20553	WASHER	6		
31	11	69254	NUT	6		
32	23	27132	BUSHING	1		
33	25	19564	GROMMET	1		
34	25	19565	GROMMET	1		
35	10	66727	SCREW (1-1/4 IN.)	1		
36	10	68783	SCREW (2-1/2 IN.)	1		
37	10	66725	SCREW (3-1/2 IN.)	3		
38		812905A 5	FRONT BRACKET ASSEMBLY	1		
39	10	805557 1	SCREW (5/16-18 X 1/2)	4		
39	10	90285	SCREW (5/8)	4		
40	12	66720	WASHER (USE WITH 5/8 IN. REF 4	4		