



				Parts List		
Ref	Class	Part	Description	Qty	Comment	Footnote
1		12430A 4	SENSOR ASSEMBLY	1		
2	10	812832 1	SCREW (10-16 X 3/5 IN.)	1		
3		56762	CABLE TIE	2		
4		12335A 1	REMOTE OIL TANK HOLD-DOWN	1		
5		12323A 1	BUNGY CORD ASSEMBLY	1		
6	1257	8742 1	OIL TANK	1		
7	36	43298A 2	CAP ASSEMBLY	1		
8	25	11332	O RING	1		
9		816190A 3	ADAPTOR HOUSING	1		
10	25	11332	O RING	1		
11	32	99802	TUBE	1		
12	21	43278 1	FITTING (CRANKCASE)	1		3,5
13	32	99439	HOSE	1		
14		815699	OIL PUMP	1		
15		814103 2	WORM BUSHING	1		
16	25	11379	O-RING	1		
17	23	99743 1	BEARING ASSEMBLY	1		5
18	43	14563	DRIVEN GEAR	1		
19	10	32228	SCREW (10-32 X 5/8 IN.)	1		
19	10	41507	SCREW (10-32 X 1-1/8 IN.)	1		
20		19385 12	LINK	1		
21	32	823813 29	TUBING (7 IN.)	1		5
22	22	42425 4	FITTING	1	(S/N-0G438000 & UP)	
22	22	42425 2	FITTING	1	(S/N-0G437999 & BELOW)	5
23	32	830756109	TUBING (6 IN.)	1		
24		99443 6	OIL RESERVOIR	1		
25	10	69020	SCREW (10-32 X 7/8 IN.)	3		
26	12	42118	WASHER	6		
27	25	42117	GROMMET	3		
28	23	42116	BUSHING	3		
29	32	823814 55	TUBING (4-3/4 IN.)	1		5
30	54	816311	STA-STRAP	AR		8
31	36	43300A 9	CAP ASSEMBLY	1		
32		99022A 1	FLOAT ASSEMBLY	1		
33	11	99265	PUSHNUT	1		
34	27	43307	GASKET	1		
-		<a href="#">823434A97</a>	POWERHEAD	1	(150)	
-		<a href="#">812817A97</a>	POWERHEAD	1	(175)	
-		<a href="#">813043A97</a>	POWERHEAD	1	(200)	