



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1647	9148A47	GEAR HOUSING	1	(BASIC-BLACK)	
1	1647	9148A48	GEAR HOUSING	1	(BASIC-GRAY)	
51		89594A 1	CAM FOLLOWER	1		
52		78956 2	SHIFT CAM	1		5
53		79911 1	ROD	1		
54	17	78906	PIN	1		
55	24	79910	SPRING	2		
56	12	78910	WASHER	AR		8
57		14469	BEARING CUP	1		
58	30	88957	BALL BEARING	1		5
59		NSS	REVERSE GEAR (PART OF 43-18)	1	(1.87:1 - 15/28)	6
60	31	15844	ROLLER BEARING	1		
61	52	823174	CLUTCH	1		
62	17	78909	DETENT PIN	2		
63	17	78905	CROSS PIN	1		
64	24	78962	SPRING	2		
65	43	18475A 1	FORWARD GEAR	1	(1.87:1 - 15/28)	
66	23	17615 1	SPACER SHIM .125 IN.	AR		8
66	23	17615 2	SPACER SHIM .127 IN.	AR		8
66	23	17615 3	SPACER SHIM .129 IN.	AR		8
66	23	17615 4	SPACER SHIM .131 IN.	AR		8
66	23	17615 5	SPACER SHIM .133 IN.	AR		8
66	23	17615 6	SPACER SHIM .135 IN.	AR		8
66	23	17615 7	SPACER SHIM .137 IN.	AR		8
66	23	17615 8	SPACER SHIM .139 IN.	AR		8
66	23	17615 9	SPACER SHIM .141 IN.	AR		8
66	23	17615 10	SPACER SHIM .143 IN.	AR		8
66	23	17615 11	SPACER SHIM .145 IN.	AR		8
66	23	17615 12	SPACER SHIM .147 IN.	AR		8
66	23	17615 13	SPACER SHIM .149 IN.	AR		8