



19030

Cowl Mounting Brackets

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		76258A 2	BRACKET, REAR COWL (BLACK)	1		
1		76258A 3	BRACKET, REAR COWL (GRAY)	1		
1		76258A 4	BRACKET, REAR COWL (OYSTER)	1		
2	22	76256	NOZZLE, TELL TALE (BLACK/GR)	1		
2	22	76256 1	NOZZLE, TELL TALE (OYSTER)	1		
3		67984	SEAL, REAR COWL BRACKET TC	1		
4		67228	SEAL, REAR COWL BRACKET TC	1		
5		67999	SEAL, REAR COWL BRACKET TC	2		
6	32	34395A 1	HOSE, TELL TALE (4")	2		
7	22	90824	TEE, TELL TALE HOSE	1		
8		73498	CLAMP, TELL TALE HOSE	2		
9		86386A 1	BRACKET ASSEMBLY, COWL SU	1		
10	10	66687	SCREW, (#10-32 x 1.50), REAR C	4		
11		85651	HOUSING, COWL HINGE - PORT	2		
11		85650	HOUSING, COWL HINGE - STARE	2		
12	10	64278	SCREW, (.250-28 x 1.00), COWL H	8		
13	12	20583	WASHER, COWL HINGE HOUSIN	8		
14	11	35888	NUT, (.250-28), COWL HINGE HOI	8		
15		99424	BRACKET, COWLING MOUNTING	1		
15		99424T 6	BRACKET, COWLING MOUNTING	1		
15		99424T 10	BRACKET, COWLING MOUNTING	1		
16		99447T	RETAINER, CABLE	1		
17	10	22411	SCREW, (.190-24 x 1.00), CABLE F	2		
18		67260	SEAL, CONTROL CABLES	1		
19		90435	MOUNT, COWL MOUNTING BRAI	3		
20	12	29245	WASHER, (.281 x .500 x .060), CO	6		
21	11	35888	NUT, (.250-28), COWL MOUNTING	6		
22		67241	HOUSING, COWL LATCH	1		
23	10	92051	SCREW, (10-16 x .75), COWL LAT	2		
24		87608	COWL LATCH	1		
25	24	60295	SPRING, COWL LATCH	1		
26		88622	PLATE, CABLE RETAINER	1		
27		99391	RETAINER, OIL LINES (OIL INJEC	1		
28	10	69067	SCREW, (.250-20 x 1.375), LOWE	2		
29	12	20346	WASHER, LOWER BRACKET SCF	4		
30	12	57427	WASHER, LOWER BRACKET SCF	4		
31	23	88180	BUSHING, LOWER BRACKET GR	2		
32	25	88033	GROMMET, LOWER BRACKET	2		
33	12	28927	WASHER, LOWER BRACKET SCF	2		