



19036

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	27	90484	GASKET, DIVIDER PLATE	2	2
2		87321	PLATE, DIVIDER	1	
3		69668	SEAL, DIVIDER PLATE	1	2
4		95067	COVER, EXHAUST MANIFOLD	1	
5	10	74824	SCREW, (.312-18 x 1.250)	21	
6		65663A	COVER, RELIEF VALVE - (OLD DE	1	
7	10	38837	SCREW, (.312-18 x 1.12), COVER	2	
8	27	88907	GASKET, RELIEF VALVE PLATE -	2	2
9		65664A	PLATE ASSEMBLY, RELIEF VALV	1	
10		64877	DIAPHRAGM (OLD DESIGN)	1	
11	12	76451	WASHER, DIAPHRAGM SCREW -	1	
12	10	69570	SCREW, (#10-16 x .750), DIAPHR	1	
13	24	64878	SPRING, COMPRESSION POPPET	1	
14		86596	POPPET VALVE, VALVE - (OLD DI	1	
15	25	64872	GROMMET, POPPET VALVE - (OL	1	
16		65848	CARRIER, POPPET VALVE - (OLD	1	
17		14462A	COVER, RELIEF VALVE - (NEW C	1	
18	10	74824	SCREW, (.312-18 x 1.250), COVEF	4	
19	27	78690	GASKET, RELIEF VALVE PLATE -	2	2
20		16497A	PLATE, RELIEF VALVE - (NEW D	1	
21		14479	DIAPHRAGM (NEW DESIGN)	1	
22		16496	WATER DEFLECTOR (NEW DESI	1	
23	12	76451	WASHER, DIAPHRAGM SCREW -	1	
24	10	69570	SCREW, (#10-16 x .750), DIAPHR	1	
25	24	64878	SPRING, COMPRESSION POPPET	1	
26		14480	POPPET, VALVE - (NEW DESIGN	1	
27	25	64872	GROMMET, POPPET VALVE - (NI	1	
28		65848	CARRIER, POPPET VALVE - (NE	1	
29	12	85303	WASHER, POPPET SPRING - (NE	1	
30		43029A	PLATE ASSEMBLY, EXHAUST (BL	1	
30		43029A	PLATE ASSEMBLY, EXHAUST (D	1	
31	22	99664	ELBOW, EXHAUST PLATE	1	
32	17	20033	PIN, Dowel, LOCATING - EXHAL	2	
33		70748	SEAL, EXHAUST PLATE (BLACK	1	
34		68010	BRACKET, SEAL RETAINING (B	1	
35	10	48408	SCREW, (#10-16 x .500), BRACK	8	
36	12	25970	WASHER, POWERHEAD STUD	6	
37	11	69254	NUT, POWERHEAD STUD	6	
38	23	27132	BUSHING, EXHAUST PLATE	1	
39	10	66727	SCREW, (.312-18 x 1.250), EXHAL	1	
40	10	68782	SCREW, (.312-18 x 1.250), EXHAUS	1	