



18956

Parts List					
Ref	Class	Part	Description	Qty	Footnote
-	1647	9148A18	GEAR HOUSING (LONG) (BLACK)	1	
-	1647	9148A19	GEAR HOUSING (X-LONG) (BLAC)	1	
-	1647	9148A20	GEAR HOUSING (LONG) (GRAY)	1	
-	1647	9148A21	GEAR HOUSING (X-LONG) (GRAY)	1	
-	1647	9148A36	GEAR HOUSING (LONG) (OYSTER)	1	
-	1647	9148A25	GEAR HOUSING (X-LONG) (OYST)	1	
1	1647	9148A11	GEAR HOUSING ASSEMBLY (BI)	1	
1	1647	9148A12	GEAR HOUSING ASSEMBLY (G)	1	
1	1647	9148A24	GEAR HOUSING ASSEMBLY (O)	1	
2	22	85822A	CONNECTOR ASSEMBLY, SP	1	
3	17	20033	PIN, Dowel, GEAR HOUSING	1	
4	16	78638	STUD, (.438 x 3.12), GEAR HO	2	
4	16	78639	STUD, GEAR HOUSING (9") -	1	
5	16	57920	STUD, (.44 x 2.06), GEAR HOL	2	
5	16	74730	STUD, GEAR HOUSING (7-1/1)	2	
6	16	56297	STUD, (.312 x 3.38), WATER F	1	
7	16	30667	STUD, (.250-20/ 250-28 x 3.12)	2	
8	31	42647A	BEARING ASSEMBLY, Roller, Df	1	
9	23	43998	SLEEVE, LUBRICATION	1	
11	45	44000	DRIVESHAFT (LONG)	1	
11	45	44209	DRIVESHAFT (EXTRA LONG)	1	
12		N.S.S.	Not Sold Seperate, Pinion Gear (F	1	
13	12	92721	WASHER, PINION GEAR	1	
14	11	35921	NUT, (.625-18), PINION GEAR T	1	
15	15	42637A	SHIM SET, ROLLER BEARING	1	AR
16	31	36387A	BEARING, Roller, DRIVE SHAFT	1	
17	11	42633	NUT, DRIVE SHAFT BEARING	1	
18	46	42579A	WATER PUMP BASE ASSEMBL	1	2
19	27	42631	GASKET, WATER PUMP TO C	1	2,11,11
20	25	90011	O-RING, (2.175 x .175), WATE	1	2,11,12
20	25	38099	O-RING, WATER PUMP (2.10)	1	2,11,12
21	26	89238	OIL SEAL, WATER PUMP	1	11,12
22	26	16977	OIL SEAL, WATER PUMP	1	11,12
23	27	85608	GASKET, LOWER - WATER P	1	2,11,12
24	27	85609	GASKET, UPPER - WATER PL	1	2,11,12
25		32435	FACE PLATE, FACE - WATER PI	1	2
26	46	96148A	WATER PUMP BODY ASSEMBL	1	2
27		48752	INSERT, WATER PUMP BOD	1	2
28	26	38970	SEAL, RUBBER - WATER INLI	1	2,11,12
29	47	89984	IMPELLER, WATER PUMP	1	2
30	28	56654	KEY, IMPELLER DRIVE	1	2