



18502

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1374	9242A33	CARBURETOR (TOP) WH-40	1		
1	1374	9242A34	CARBURETOR (CENTER) WH-40	1		
1	1374	9242A35	CARBURETOR (BOTTOM) WH-40	1		
1	1374	9242A48	CARBURETOR (TOP) WH-48	1		
1	1374	9242A49	CARBURETOR (CENTER) WH-48	1		
1	1374	9242A50	CARBURETOR (BOTTOM) WH-48	1		
1	1382	7563A10	CARBURETOR (TOP) WH-35	1		
1	1382	7563A11	CARBURETOR (CENTER) WH-35	1		
1	1382	7563A12	CARBURATOR (BOTTOM) WH-35	1		
1	1382	7563A13	CARBURETOR (TOP) WH-38	1		
1	1382	7563A14	CARBURETOR (CENTER) WH-38	1		
1	1382	7563A15	CARBURETOR (BOTTOM) WH-38	1		
2	1399	6249	JET, (.096), FUEL BOWL (WH-35)	6		
2	1395	8423	JET, FUEL BOWL (.094) (WH-35)	6		
2	1395	6680	JET, (.078), FUEL BOWL (WH-40)	6		
3		NSS	NOT SOLD SEPARATE, Gasket	3		4,5,6
4	1395	6032	PLATE, COVER	3		
5		NSS	NOT SOLD SEPARATE, Screw	15		5,6
6	1395	7823	FUEL BOWL (CENTER/BOTTOM)	2		
7		NSS	NOT SOLD SEPARATE, Screw	18		5,6
9	1395	6025	PLUG, MAIN JET	6		4,5,6
10	1395	6028	JET, (.050), MAIN FUEL (WH-35)	6		
10	1395	6359	JET, (.052), MAIN FUEL (WH-38)	6		
10	1395	6201	JET, (.080), MAIN FUEL (WH-40)	6		
11		NSS	NOT SOLD SEPARATE, Screw	6		5,6
12		NSS	NOT SOLD SEPARATE, Gasket	6		4,5,6
13	1395	7824	INLET NEEDLE AND SEAT ASS	6		
14		NSS	NOT SOLD SEPARATE, Gasket	6		4,5,6
15	1395	9267	FLOAT	6		
16		NSS	NOT SOLD SEPARATE, Pin-Float	6		5,6
17		NSS	NOT SOLD SEPARATE, Gasket	3		4,5,6
18	1395	4541	SCREW, IDLE AIR BLEED JET	6		
19		NSS	NOT SOLD SEPARATE, Gasket	6		4,5,6
20	1395	6487	JET, (.060), IDLE AIR BLEED (w/)	6		
20	1399	5317	JET, (.046), IDLE AIR BLEED (w/)	6		
20	1395	6246	JET, (.048), IDLE AIR BLEED (w/)	6		
20	1395	7394	JET, (.044), IDLE AIR BLEED (w/)	6		
21	1395	6027	SCREW, THROTTLE LEVER	3		
22		814679	LEVER, THROTTLE	3		
23		NSS	NOT SOLD SEPARATE, Spring	3		5,6
24	1395	6021	SPACER, THROTTLE LEVER	2		