



18520

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	1590	8343A 7	DRIVESHAFT HOUSING ASSEMBLY	1	
1	1590	8343A 8	DRIVESHAFT HOUSING ASSEMBLY	1	
1	3503	9748A 1	DRIVESHAFT HOUSING, X-LONG	1	
1	3503	9748A 2	DRIVESHAFT HOUSING, X-LONG	1	
2	16	56295	STUD, (.437 x 2.69), DRIVE SHAFT	2	
3		25067	BUMPER, LOWER MOUNT SCREW	2	
4	10	63474	SCREW, (.500-20 x 6.00), LOWER MOUNT	2	
5		78249	MOUNT, LOWER (LONG)	2	
5		77327	MOUNT, LOWER (X-LONG)	2	
6	12	49339	WASHER, (.8125), LOWER MOUNT	2	
7	11	25096	NUT, LOWER MOUNT SCREW	2	
8		88238A 1	GROUND WIRE ASSEMBLY	1	
9	54	67076	CLAMP, LOWER MOUNT	2	
10	10	66727	SCREW, (.312-18 x 1.250), LOWER MOUNT	4	
11		67077	COVER, LOWER MOUNT CLAMP	2	
11		67077T 6	COVER, LOWER MOUNT CLAMP	2	
12	10	88417	SCREW, (#12-24 x .620), COVER CLAMP	4	
13	11	35521	NUT, NYLON - COVER TO CLAMP	4	
14		88238A 2	GROUND STRAP	1	
15	10	41508	SCREW, (.250-20 x .500), GROUND STRAP	1	
16	12	73862	WASHER, GEAR HOUSING STUD	1	
17	11	29489	NUT, GEAR HOUSING STUD (CAL)	1	
18	12	45176	WASHER, (.453 x .812 x .105), GEAR HOUSING	2	
19	11	34933	NUT, (.437-20), GEAR HOUSING STUD	2	
20	19	64649	PLUG, DRIVE SHAFT HOUSING	1	
21		89743	EXHAUST TUBE	1	
22		66350	SEAL, EXHAUST TUBE - LOWER	1	
23		86027	SEAL, EXHAUST TUBE - UPPER	1	
24	32	67295	TUBE, WATER (LONG SHAFT)	1	
24	32	74729	TUBE, WATER (EXTRA LONG SHAFT)	1	
25	27	99173 1	GASKET, DRIVE SHAFT HOUSING	1	1
26		41945A 7	PLATE ASSEMBLY, DRIVE SHAFT	1	
27		18398 2	SEAL, BRACKET	1	
28		68011	BRACKET, SEAL RETAINING	1	
29	10	48408	SCREW, (#10-16 x .500), BRACKET	12	
30	17	20033	PIN, Dowel, LOCATING	2	
31	26	38970	SEAL, WATER TUBE	1	1
32	10	90192	SCREW, (.250-20 x .750), EXHAUST TUBE	6	
33	27	99177 1	GASKET	1	1
34	12	25970	WASHER, POWER HEAD STUD	4	
35	11	68254	NUT, POWER HEAD STUD	4	