



18521

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1499	8710A17	SWIVEL BRACKET ASSEMBLY (B	1		
1	1499	8710A18	SWIVEL BRACKET ASSEMBLY (G	1		
2	26	87735	SEAL, OIL, SWIVEL BRACKET (L	1		
3	23	67669	BUSHING, SWIVEL BRACKET -	2		
4	25	33466	O-RING, SWIVEL BRACKET - UF	1		1
5	23	67668	SPACER, SWIVEL BRACKET - L	1		
6	22	74036	FITTING, Grease	2		
7	23	99608	BUSHING, SWIVEL BRACKET	2		
8	17	67706A30	SWIVEL PINE AND STEERING AF	1		
8	17	67706A31	SWIVEL PINE AND STEERING AF	1		
9	10	78689	SCREW, (.437-20 x 7.50), STEERIII	2		
10		78687	MOUNT, RUBBER - UPPER (LONI)	2		
10		77326	MOUNT, RUBBER - UPPER (X-LO)	2		
11	12	66921	WASHER, UPPER MOUNT BOLT	2		
12	12	78688	WASHER, UPPER MOUNT BOLT	2		
13	11	34933	NUT, (.437-20), UPPER MOUNT B	2		
14		92876A	STEERING LINK ASSEMBLY	1	MERCURY AND MARINER	
15	10	14000	SCREW, (.375-24 x 1.25), STEERIII	1	MERCURY AND MARINER	
16	11	34863	NUT, (.375-24), STEERING LINK E	2	MERCURY AND MARINER	
17	12	34931	WASHER, (.406 x .734 x .063) SS,	2	MERCURY AND MARINER	
18	13	78854	WAVE WASHER, BOTTOM YOKE	1		
19		86580A	BOTTOM YOKE	1		
19		86580A	BOTTOM YOKE	1		
20	53	67684	RETAINING RING, BOTTOM YOK	1		
21	12	67670	WASHER, THRUST - SWIVEL BR	1		
22		88882	BUMPER, TOP YOKE	1		
23		95164A	TRIM SENDER ASSEMBLY	1		
24	10	56682	SCREW, (#10-24 x .750), TRIM SE	2		
25	13	26996	LOCKWASHER, (#10), TRIM SENI	2		
26	12	89302	WASHER, (.203 x .406 x .040), TR	2		
27	10	64014	SCREW, (.250-28 x .500), SWIVEL	2		
28	54	54457	J CLIP	1		