



8962

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1499	8710A20	SWIVEL BRACKET ASSEMBLY (I	1		
1	1499	8710A21	SWIVEL BRACKET ASSEMBLY (G	1		
2	26	87735	SEAL, OIL, SWIVEL BRACKET (L	1		
3	23	67669	BUSHING, SWIVEL BRACKET-L	2		
4	23	816039	SPACER	1		
5	25	33504	O-RING	1		
6	22	74036	FITTING, Grease	2		
7	23	99608	BUSHING, SWIVEL BRACKET	2		
8	12	816432	THRUST WASHER,	1		
9	10	78689	SCREW, (.437-20 x 7.50), STEERII	2		
10		78687	MOUNT, RUBBER-UPPER (LONG	2		
10		77326	MOUNT (X-LONG) (USE ON XR4/I	2		
11	12	66921	WASHER, UPPER MOUNT BOLT	2		
12	12	814432	WASHER, UPPER MOUNT BOLT	2		
13	11	34933	NUT, (.437-20), UPPER MOUNT B	2		
14		92876A	STEERING LINK ASSEMBLY	1		
15	10	14000	SCREW, (.375-24 x 1.25), STEERII	1		
16	11	34863	NUT, (.375-24), STEERING LINK E	2		
17	12	34931	WASHER, (.406 x .734 x .063) SS,	2		
18	17	67706A35	SWIVEL PIN AND STEERING ART	1		
18	17	67706A36	SWIVEL PIN AND STEERING ART	1		
19		86580A	BOTTOM YOKE (BLACK)	1		
19		86580A	BOTTOM YOKE (GRAY)	1		
20	53	67684	RETAINING RING, BOTTOM YOK	1		
21		88882	BUMPER, TOP YOKE	1		
22	10	64014	SCREW, (.250-28 x .500), SWIVEL	2		
23	54	54457	J CLIP			
24		95164A	TRIM SENDER ASSEMBLY	1		
25	10	56682	SCREW, (#10-24 x .750)	2		
26	13	26996	LOCKWASHER, (#10)	2		
27	12	89302	WASHER, (.203 x .406 x .040)	2		